| Original | Sustituto |
|---|---|
| AVR/AVC On | Power |
| AVR/AVC Off | SHIFT + Power |
| Power Tv | TV/R |
| Power VCR | Smart |
| Power DVD/VDP | Media |
| PHONO | 1 |
| CD | 2 |
| DVD/VDP | 3 |
| VCR-1 | 4 |
| VCR-2 / V. AUX | 5 |
| TV/DBS | 6 |
| MD/Tape Mon | 7 |
| Tuner | 8 |
| Shift | 9 |
| Video Select | 0 |
| Input Mode | Guide |
| Surround Mode | Pre Ch |

| Original | Sustituto |
|---|---|
| << Deck-VCR | SHIFT + << |
| < Deck-VCR | SHIFT + Play |
| Deck-VCR > | SHIFT + Pause |
| Deck-VCR >> | SHIFT + >> |
| Stop Deck-VCR | SHIFT + Stop |
| CH+ | Ch + |
| CH- | Ch - |
| Disc Skip+ | Blue |
| Play CD/MD/CDR-DVD/ | Play |
| Stop CD/MD/CDR-DVD/ | Stop |
| Pause CD/MD/CDR-DVD/ | Pause |
| CD/MD/CDR-DVD/ VDP >>I | >>I |
| I << CD/MD/CDR-DVD/ | I << |
| CD/MD/CDR-DVD/ VDP >> | >> |
| << CD/MD/CDR-DVD/ | << |
| System/Setup | Menu |
| Surround/Menu | D. Menu |

| Original | | Sustituto | | Original | Sustituto |
|---|---|---|---|---|---|
| T.TONE RETURN | T. Tone/ Return | RETURN BACK | Back | | |
| STATUS DISPLAY | Status/ Display | DISPLAY INFO | Info | | |
| ▲ | Up | ▲ | Up | | |
| ▼ | Down | ▼ | Down | | |
| ▶ | Right | ▶ | Right | | |
| ◀ | Left | ◀ | Left | | |
| CH.SELECT SELECT | CH. Select/ Select | OK | Ok | | |
| MASTER VOL ▲ | Master Volume | + VOL | Vol + | | |
| MASTER VOL ▼ | Master Volum | VOL − | Vol - | | |
| MUTING | Muting | MUTE | Mute | | |
| VOLUME ▲ | Tv Vol + | SHIFT + | + VOL Shift + Vol + | | |
| VOLU ▼ | Tv Vol - | SHIFT + | VOL − Shift + Vol - | | |
| CHANNEL + | Tv CH+ | SHIFT + | + CH Shift + Ch + | | |
| CHAN − | Tv CH- | SHIFT + | CH − Shift + Ch - | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| AVR/AVC On | Power | | |
| AVR/AVC Off | SHIFT + Shift + Power | | |
| Play CD/MD/CDR-DVD/ | PLAY MODE Play | | |
| Pause CD/MD/CDR-DVD/ | Pause | | |
| Stop CD/MD/CDR-DVD/ | Stop | | |
| CD/MD/CDR-DVD/ VDP >>I | >>I | | |
| I << CD/MD/CDR-DVD/ | I << | | |
| CD/MD/CDR-DVD/ VDP >> | >> | | |
| << CD/MD/CDR-DVD/ | << | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Sustituto |
|---|---|
| AVR/AVC On | Power |
| AVR/AVC Off | Shift + Power |
| CH+ | Ch + |
| CH- | Ch - |
| Deck-VCR >> | >> |
| << Deck-VCR | << |
| Deck-VCR > | Shift + Pause |
| Stop Deck-VCR | Shift + Stop |
| Title CD/MD/CDR-DVD/ | Exit |
| Disc Skip+ CD/MD/CDR-DVD/ | Blue |
| Play CD/MD/CDR-DVD/ | Play |
| Pause CD/MD/CDR-DVD/ | Pause |
| Stop CD/MD/CDR-DVD/ | Stop |
| CD/MD/CDR-DVD/ VDP >>I | >>I |
| I << CD/MD/CDR-DVD/ | I << |
| System/Setup | Menu |
| Surround/Menu | D. Menu |

| Original | Sustituto |
|---|---|
| T.TONE RETURN | T.Tone/Return |
| STATUS DISPLAY | Status/Display |
| Up | Up |
| Down | Down |
| Right | Right |
| Left | Left |
| CH.SELECT SELECT | CH.Select/Select |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Sustituto |
|---|---|
| RETURN BACK | Back |
| DISPLAY INFO | Info |
| Up | Up |
| Down | Down |
| Right | Right |
| Left | Left |
| OK | Ok |