Mandis shop

RM-S755

| Original | | Sustituto | |
|---|---|---|---|
| SYSTEM POWER | System Power | | Power |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| FUNCTION | Function | TOP MENU MENU | Menu |
| TAPE | Deck A > | | Right |
| | < Deck A | | Left |
| | >> Deck A | | Up |
| | << Deck A | | Down |
| | Stop Deck A | OK | Ok |
| | Deck B > | B | Green |
| | < Deck B | A | Red |
| | Deck B >> | | >> |
| | << Deck B | | << |
| | Pause Deck B | C | Yellow |
| | Stop Deck B | D | Blue |
| REC | Rec Deck B | REC MODE | Rec |
| | Play CD | PLAY MODE | Play |
| | Stop CD | | Stop |

| Original | | Sustituto | |
|---|---|---|---|
| | Pause CD | | Pause |
| | I<< CD | | I<< |
| | >>I CD | | >>I |
| STEREO/ MONO | Stereo/Mono | SOUND DUAL | Dual |
| BAND | Tuner/Band | SEARCH TV/R | TV/R |
| PRESET + | Preset+ | + CH | Ch + |
| PRESET − | Preset- | CH − | Ch - |
| VOL + | Vol+ | + VOL | Vol + |
| VOL − | Vol- | VOL − | Vol - |
| EQ PRESET | EQ Preset | HOME SMART | Smart |
| DISPLAY | Display | DISPLAY INFO | Info |
| CLOCK DISPLAY | Clock Display | TIMER AV | AV |
| EFFECT | Effect | APP MEDIA | Media |

https://mandos-a-distancia.es/es/Sony/1062011-77649-mando-de-sustitucion-para-Sony-RM-S755.html