Original		Sustituto	
ON/STAND-BY	On/Standby		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
10+	10+	GUIDE	Guide
REPEAT	Back/Repeat	RETURN BACK	Back
MEMORY	Memory	HOME SMART	Smart
CLEAR	Clear	CLEAR EXIT	Exit
CLOCK/TIMER	Clock/Timer	TIMER AV	AV

Original		Sustituto	
SLEEP	Sleep	PROG SLEEP	Sleep
BASS/TREBLE	Bass/Treble	SETTINGS OPT	Options
X-BASS	X-Bass	SOUND DUAL	Dual
RANDOM	Random	AD SUBT	Subt
TUNING	<<|<<|Tuning		<<
TUNING	>>|>>|Tuning		>>
FOLDER	Folder	REPEAT TEXT	Text
DEMO/ DIMMER	Demo/Dimmer	DISPLAY INFO	Info
PRESET	Preset Up		Up
PRESET	Preset Down		Down
ENTER	Enter	OK	Ok
+ VOL	Vol+	+ VOL	Vol +
+ VOL	Vol+		Right
VOL −	Vol-	VOL −	Vol -
VOL −	Vol-		Left
	Mute	MUTE	Mute
CD	CD	C	Yellow

Original		Sustituto	
USB	USB	B	Green
TUNER	Tuner	D	Blue
AUDIO/LINE INPUT	Input/Audio/Line	A	Red
iPod	iPod	ECO 3D	3D
DISPLAY (TV OUT)	(Tv Out)/Display	SEARCH TV/R	TV/R
MENU	Menu	TOP MENU MENU	Menu
▶/II	Play/Pause iPod	PLAY MODE ▶	Play
DISPLAY	Display CD/USB	+ CH	Ch +
■	Stop CD/USB	■	Stop
▶/II	Play/Pause	II	Pause
ASPM	ASPM RDS	E-MANUAL D.MENU	D. Menu
PTY	PTY RDS	PICTURE FORMAT	Format
DISPLAY	Display RDS	CH −	Ch -

Original	Sustituto