Mandis shop

RM-SD50

Original		Sustituto	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
LOOP	Loop	HOME SMART	Smart
CD	Play CD	PLAY MODE	Play
	Pause CD		Pause
	Stop CD		Stop
TUNER/BAND	Play	C	Yellow
	I<< Tuner/Band		I<<
	>>I Tuner/Band		>>I
DECK A	Play Deck A	A	Red
	<< Deck A		<<
	>> Deck A		>>
DECK B	Play Deck B	B	Green
CHECK	Check	FAV PRE-CH	Pre Ch
EDIT	Edit	D	Blue
FUNCTION	Function	TOP MENU MENU	Menu
CLEAR	Clear	CLEAR EXIT	Exit

Original		Sustituto	
DISC SKIP	Disc Skip	APP MEDIA	Media
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ON/OFF	On/Off	OK	Ok

https://mandos-a-distancia.es/es/Sony/1063680-90875-mando-de-sustitucion-para-Sony-RM-SD50.html