Mandis shop

# KODA IP915

| Original | | Sustituto | |
|---|---|---|---|
| | POWER | | Power |
| | MUSIC | SEARCH TV/R | TV/R |
| menu | MENU | TOP MENU MENU | Menu |
| enter | ENTER | OK | Ok |
| | UP | | Up |
| | DOWN | | Down |
| | >>I | | >>I |
| | >>I | | Right |
| | >>I | | >> |
| | I<< | | << |
| | I<< | | I<< |
| | I<< | | Left |
| | PLAY / PAUSE | PLAY MODE | Play |
| | PLAY / PAUSE | | Pause |
| mute | MUTE | MUTE | Mute |
| memory | MEMORY | E-MANUAL D.MENU | D. Menu |
| stereo mono | STEREO / MONO | SOUND DUAL | Dual |

| Original | | Sustituto | |
|---|---|---|---|
| | CLOCK | PROG SLEEP | Sleep |
| dimmer | DIMMER | REPEAT TEXT | Text |
| eq reset | EQ RESET | SETTINGS OPT | Options |
| bass | BASS+ | HOME SMART | Smart |
| bass | BASS- | APP MEDIA | Media |
| treble | TREBLE+ | CH + | Ch + |
| treble | TREBLE- | CH − | Ch - |
| | Vol- | VOL − | Vol - |
| | Vol+ | VOL + | Vol + |
| | Repeat | RETURN BACK | Back |

https://mandos-a-distancia.es/es/KODA/1064357-95041-mando-de-sustitucion-para-KODA-IP915.html