| Original | | Sustituto | |
|---|---|---|---|
| | Power | | Power |
| MUTING | Muting | DIMMER MUTE | Mute / Dimmer |
| DVD/CD | Play DVD/CD | SLOW | Play / Slow |
| DISC PAUSE | Pause/Disc Pause | STEP-FREEZE | Pause / Step / Freeze |
| STOP | Stop | HOLD | Stop / Hold |
| REC | Rec | REC MODE | Rec / Rec Mode |
| SLOW/SE | << Slow/Search | TUNE- | << / Tune- |
| /SEARCH | Slow/Search >> | TUNE+ | >> / Tune+ |
| V/REW | I<</Rew | PRESET- | I<< / Preset- |
| ∧/FF | >>I/FF | PRESET+ | >>I / Preset+ |
| SOUND | Sound | TITLE SOUND | Sound / Title |
| M.RE-MASTER | M. Re-master | LANG I/II AUDIO | Audio / Lang I/II |
| SUBWOOFER | Subwoofer | EQ SUBTITLE | Subtitle / EQ |
| SURROUND | Surround | SURROUND | Eject / Surround |
| GROUP | Group | FORMAT PICTURE | Picture / Format |
| A.ONLY | A.Only | SIZE ZOOM | Zoom / Size |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |

| Original | | Sustituto | |
|---|---|---|---|
| ALL DISC | All Disc | PROGRAM TV/ RADIO | TV/Radio / |
| TOP MENU DIRECT NAVIGATOR | Top Menu/Direct Navigator | TOP MENU D.MENU | D.Menu / Top |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| Q.REPLAY | Q Replay | GOTO TEXT | Text / Goto |
| TV/AV | Tv/AV | RDS AV INPUT | AV / Input / RDS |
| MENU PLAY LIST | Menu/Play List | HOME MENU | Menu / Home |
| | Up | | Up |
| P.MEMORY | P.Memory | ANGLE INFO | Info / Angle |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |
| CANCEL | Cancel | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Down | | Down |
| RETURN | Return | RETURN BACK | Back / Return |
| LUME | Vol+ | VOL | Vol+ |
| AUTO OFF | Auto Off | LIST SMART | Smart / List |
| TV CH ∧ | Tv CH+ | CH PAGE | CH+ / Page+ |

| Original | | Sustituto | |
|---|---|---|---|
| VOL | Vol- | VOL – | Vol- |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| V TV CH | Tv CH- | CH PAGE – | CH- / Page- |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| ≧10 | >10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 | HDMI-SAT 0 | 0 |
| PGM | PGM | PC FAV MARKER | Fav / Marker / PC |
| ANGLE/PAGE | Angle/Page | NETFLIX SEARCH | Red / Netflix / Search |
| REPEAT | Repeat | APP REPEAT | Green / APP / Repeat |

| Original | | Sustituto | |
|---|---|---|---|
| DISC | Disc | Prime Video RANDOM | Blue / Prime Video / Random |
| TV⏻ | Tv Power | SHIFT + ⏻ | Shift + Power |
| DIMMER | Dimmer | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer |
| TAPE ◀▶ | <> Tape | SHIFT + STEP-FREEZE ⏸ | Shift + Pause / Step / |
| PLAY MODE | Play Mode | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| PLAY/REC | Play/Rec | SHIFT + REC MODE ● | Shift + Rec / Rec Mode |
| CLOCK/TIMER | Clock/Timer | SHIFT + TIMER SLEEP | Shift + Sleep / Timer |
| TV VOL + | Tv Vol+ | SHIFT + + VOL | Shift + Vol+ |
| – TV VOL | Tv Vol- | SHIFT + VOL – | Shift + Vol- |
| FL DISPLAY | FL Display | SHIFT + MEDIA DISPLAY | Shift + Display / Media |
| TUNER/AUX | Tuner/AUX | SHIFT + TUNER 6 | Shift + 6 |