Mandis shop

RMSXLMC2000JR

Original		Sustituto	
POWER	Power		Power
CONTINUE	Continue	OPT-TOOLS SETUP	Setup / OPT /
ONE DISC	One Disc	TOP MENU D.MENU	D.Menu / Top
PROGRAM	Program	LIST SMART	Smart / List
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
INTRO	Intro	EQ SUBTITLE	Subtitle / EQ
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
EXCHANGE	Exchange	GOTO TEXT	Text / Goto
DISC	Disc	RDS AV INPUT	AV / Input / RDS
TRACK	Track	FORMAT PICTURE	Picture / Format
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6

Original		Sustituto	
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
CALL	Call	SIZE ZOOM	Zoom / Size
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MEMORY	Memory	MEDIA DISPLAY	Display / Media
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
-1 DISC	-1 Disc	CH PAGE	CH- / Page-
+1 DISC	+1 Disc	CH PAGE	CH+ / Page+