Mandis shop

JVC RMSUXG6R

Original	Sustituto
PANEL OPEN/CLOSE — Open/Close	SURROUND — Eject / Surround
DIMMER — Dimmer	DIMMER MUTE — Mute / Dimmer
⏻/I — Power	Power
ACTIVE BASS EX. — Active Bass EX.	EQ SUBTITLE — Subtitle / EQ
CLOCK/TIMER — Clock/Timer	SHIFT + TIMER SLEEP — Shift + Sleep / Timer
SLEEP — Sleep	TIMER SLEEP — Sleep / Timer
BASS — Bass	TITLE SOUND — Sound / Title
TREBLE — Treble	LANG I/II AUDIO — Audio / Lang I/II
FM MODE — FM Mode	+ CH PAGE — CH+ / Page+
PLAY MODE — Play Mode	HOME MENU — Menu / Home
REPEAT — Repeat	APP REPEAT — Green / APP / Repeat
AUTO PRESET — Auto Preset	CH PAGE − — CH- / Page-
PTY/EON — PTY/EON	RETURN BACK — Back / Return
TITLE/EDIT — Title/Edit	ANGLE INFO — Info / Angle
ENTER — Enter	LIST SMART — Smart / List
DISPLAY /CHARA. — Display/Chara.	MEDIA DISPLAY — Display / Media
UP — Up	▲ — Up

Original	Sustituto
CANCEL — Cancel	CLEAR EXIT CANCEL — Exit / Cancel / Clear
< — Left	< — Left
SET — Set	OK — OK
> — Right	> — Right
▶/II MD — Play/Pause MD	STEP-FREEZE II — Pause / Step / Freeze
DOWN — Down	▼ — Down
AUX — AUX	AUX-HDD 7 — 7
TAPE — <> Tape	TUNE+ ▶▶ — >> / Tune+
FM/AM — FM/AM	TUNER 6 — 6
CD ▶/II — Play/Pause CD	SLOW ▶ — Play / Slow
I<< — I<<	PRESET- I<< — I<< / Preset-
■ — Stop	HOLD ■ — Stop / Hold
>>I — >>I	PRESET+ >>I — >>I / Preset+
+ VOLUME — Volume+	+ VOL — Vol+
VOLUME − — Volume-	VOL − — Vol-

https://mandos-a-distancia.es/es/JVC/1065394-12352-mando-de-sustitucion-para-JVC-RMSUXG6R.html