Original	Sustituto	Original	Sustituto
[+]	Zoom / Size	Left	Left
Power	Power	Right	Right
Source/[?]	AV / Input / RDS	Vol +	Vol +
>>	>> / Tune+	Vol -	Vol -
Red/Rec	Red / Netflix / Search	Mute	Mute / Dimmer
Green	Green / APP / Repeat	P+	CH+ / Page+
<<	<< / Tune-	P-	CH- / Page-
Yellow	Yellow / YouTube / Repeat	1	1
Stop	Stop / Hold	2	2
Blue	Blue / Prime Video / Random	3	3
Play	Play / Slow	4	4
Radio	TV/Radio /	5	5
[≡]	Text / Goto	6	6
[ ]	D.Menu / Top	7	7
Menu	Menu / Home	8	8
Up	Up	9	9
Down	Down	0	0

Original		Sustituto		Original		Sustituto	
	[i+]	ANGLE INFO	Info / Angle				
	I-II	LANG I/II AUDIO	Audio / Lang I/II				
	[1|2]	EQ SUBTITLE	Subtitle / EQ				
	[:≡]	-/-- GUIDE EPG	Guide / EPG / -/--				
	[<>]	FORMAT PICTURE	Picture / Format				
	P<P	PC FAV MARKER	Fav / Marker / PC				
	♪/Smart	LIST SMART	Smart / List				
	[ ]/Smart	MEDIA DISPLAY	Display / Media				

Original	Sustituto
Power SAT	SHIFT + Power (Shift + Power)
Power	Power
Source/[?]	RDS AV INPUT (AV / Input / RDS)
Source SAT	SHIFT + RDS AV INPUT (Shift + AV / Input / RDS)
>>	TUNE+ (>> / Tune+)
Red SAT	NETFLIX SEARCH (Red / Netflix / Search)
<<	TUNE- (<< / Tune-)
Green SAT	APP REPEAT (Green / APP / Repeat)
Yellow SAT	YouTube REPEAT A-B (Yellow / YouTube / Repeat)
Stop	HOLD (Stop / Hold)
Play	SLOW (Play / Slow)
Blue SAT	Prime Video RANDOM (Blue / Prime Video / Random)
Radio	PROGRAM TV/RADIO (TV/Radio /)
[≡]	GOTO TEXT (Text / Goto)
Up	Up
Up SAT	SHIFT + Up (Shift + Up)
Down	Down

Original	Sustituto
Down SAT	SHIFT + Down (Shift + Down)
Left SAT	SHIFT + Left (Shift + Left)
Left	Left
Right SAT	SHIFT + Right (Shift + Right)
Right	Right
OK SAT	SHIFT + OK (Shift + OK)
OK	OK
[ ] SAT	SHIFT + RETURN BACK (Shift + Back / Return)
[ ]	RETURN BACK (Back / Return)
Menu SAT	TOP MENU D.MENU (D. Menu / Top)
Menu	HOME MENU (Menu / Home)
Vol +	VOL + (Vol +)
Vol -	VOL - (Vol -)
Mute	DIMMER MUTE (Mute / Dimmer)
P+ SAT	SHIFT + CH PAGE + (Shift + CH+ / Page-)
P+	CH PAGE + (CH+ / Page+)
P- SAT	SHIFT + CH PAGE - (Shift + CH- / Page-)

Original		Sustituto	
P-		CH- / Page-	
1 SAT		Shift + 1	
1		1	
2 SAT		Shift + 2	
2		2	
3 SAT		Shift + 3	
3		3	
4 SAT		Shift + 4	
4		4	
5 SAT		Shift + 5	
5		5	
6 SAT		Shift + 6	
6		6	
7 SAT		Shift + 7	
7		7	
8 SAT		Shift + 8	
8		8	

Original		Sustituto	
9 SAT		Shift + 9	
9		9	
0 SAT		Shift + 0	
0		0	
[i+]		Info / Angle	
I-II		Audio / Lang I/II	
[<>]		Picture / Format	
P<P		Fav / Marker / PC	

Original	Sustituto
Power	Power
>>	>> / Tune+
<<	<< / Tune-
Stop	Stop / Hold
Play	Play / Slow
Radio	TV/ Radio /
[ ]	Back / Return
Up	Up
Down	Down
Left	Left
Right	Right
Vol +	Vol +
Vol -	Vol -
Mute	Mute / Dimmer
P+	CH+ / Page+
P-	CH- / Page-
1	1

Original	Sustituto
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
[i+]	Info / Angle
I-II	Audio / Lang I/II

Original	Sustituto
Power AMP	SHIFT + Power: Shift + Power
Power	Power
Source/[?]	AV INPUT: AV / Input / RDS
>>	TUNE+: >> / Tune+
>> AMP	PRESET+: >>I / Preset+
Red	NETFLIX SEARCH: Red / Netflix / Search
Rec	REC MODE: Rec / Rec Mode
<< AMP	PRESET-: I<< / Preset-
Green	APP REPEAT: Green / APP / Repeat
<<	TUNE-: << / Tune-
Yellow	YouTube REPEAT A-B: Yellow / YouTube / Repeat
Stop	HOLD: Stop / Hold
Blue	Prime Video RANDOM: Blue / Prime Video / Random
Play	SLOW: Play / Slow
Radio AMP	PROGRAM TV/RADIO: TV/Radio /
[≡] AMP	GOTO TEXT: Text / Goto
[ ]	RETURN BACK: Back / Return

Original	Sustituto
MENU: Menu	HOME MENU: Menu / Home
MENU: Menu AMP	TOP MENU D.MENU: D.Menu / Top
Up AMP	SHIFT + ▲: Shift + Up
Up	▲: Up
Down	▼: Down
Down AMP	SHIFT + ▼: Shift + Down
Left	◀: Left
Left AMP	SHIFT + ◀: Shift + Left
Right	▶: Right
Right AMP	SHIFT + ▶: Shift + Right
OK: OK	OK: OK
OK: OK AMP	SHIFT + OK: Shift + OK
Vol + AMP	SHIFT + LIST SMART: Shift + Smart / List
Vol +	VOL +: Vol +
Vol -	VOL −: Vol -
Mute AMP	SHIFT + DIMMER MUTE: Shift + Mute / Dimmer
Mute	DIMMER MUTE: Mute / Dimmer

Original	Sustituto
P+	CH+ / Page+
P+ AMP	Shift + CH+ /
P- AMP	Shift + CH- /
P-	CH- / Page-
1 AMP	Shift + 1
1	1
2 AMP	Shift + 2
2	2
3 AMP	Shift + 3
3	3
4 AMP	Shift + 4
4	4
5 AMP	Shift + 5
5	5
6 AMP	Shift + 6
6	6
7 AMP	Shift + 7

Original	Sustituto
7	7
8 AMP	Shift + 8
8	8
9 AMP	Shift + 9
9	9
0 AMP	Shift + 0
0	0
[i+]	Info / Angle
I-II	Audio / Lang I/II
[1|2] AMP	Subtitle / EQ
[+]	Zoom / Size
[<>]	Picture / Format
P<P	Fav / Marker / PC
♪/Smart	Smart / List
[ ]/Smart	Display / Media