Mandis shop

Yamaha RAX7

Original		Sustituto	
AUX	AUX	AUX-HDD 7	7
AUX	AUX 2	USB 8	8
AUX	AUX 3	BLUETOOTH 9	9
DIR A	Tape DIR. A	NETFLIX SEARCH	Red / Netflix / Search
DIR B	Tape DIR. B	APP REPEAT	Green / APP / Repeat
	Tape	REC MODE	Rec / Rec Mode
PLAY	Tape PLAY	SLOW	Play / Slow
TAPE 2	TAPE 2	TAPE 5	5
	Tape <<	TUNE-	<< / Tune-
	Tape >>	TUNE+	>> / Tune+
	Tape STOP	HOLD	Stop / Hold
A/B	Tape A/B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TAPE 1	TAPE 1	VIDEO 4	4
PRESET -	Tuner PRESET -	PRESET-	I<< / Preset-
PRESET +	Tuner PRESET +	PRESET+	>>I / Preset+
A/B/C/D/E	Tuner A/B/C/D/E	LIST SMART	Smart / List
TUNER	TUNER	TUNER 6	6

Original		Sustituto	
	CD <<	SHIFT + TUNE-	Shift + << /
	CD >>	SHIFT + TUNE+	Shift + >> /
DISC	CD Disc	MEDIA DISPLAY	Display / Media
PLAY	CD PLAY	SHIFT + SLOW	Shift + Play /
CD	CD	CD-STB 3	3
	CD I<<	SHIFT + PRESET-	Shift + I<< / Preset-
	CD >>I	SHIFT + PRESET+	Shift + >>I / Preset+
	CD PAUSE/STOP	SHIFT + HOLD	Shift + Stop /
	CD PAUSE/STOP	SHIFT + STEP-FREEZE	Shift + Pause / Step /
PHONO	PHONO	DVD 2	2
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
STANDBY/ON	Standby/On		Power
VOL	Volume-	VOL –	Vol -
VOL	Volume+	VOL +	Vol +
	Phono Play/Cut	STEP-FREEZE	Pause / Step / Freeze