Mandis shop

Sony RM-S6

Original		Sustituto	
CD	CD	3	3
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
POWER	Power		Power
▶	Play	SLOW ▶	Play / Slow
⏸	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
⏏	Open/Close	SURROUND ⏏	Eject / Surround
⏮	I <<	TUNE- ⏮	<< / Tune-
⏭	>>I	TUNE+ ⏭	>> / Tune+
TAPE	Tape	TAPE 5	5
TUNER	Tuner	TUNER 6	6
SHIFT	Shift	APP REPEAT	Green / APP / Repeat
PHONO	Phono	TV 1	1
+ PRESET	Preset +	PRESET+ ⏭	>>I / Preset +
+	Vol +	+ VOL	Vol +
VIDEO/AUX	Video/AUX	VIDEO 4	4
PRESET -	Preset -	PRESET- ⏮	I << / Preset -

Original		Sustituto	
−	Vol -	VOL −	Vol -