Original	Sustituto	Original	Sustituto
Power	Power	i / OSD	Display / Media
1	1	Z/ Disc Menu	Menu / Home
2	2	Up	Up
3	3	P+	CH+ / Page+
PIP	Info / Angle	Left	Left
4	4	Vol -	Vol -
5	5	OK	OK
6	6	Right	Right
[<>]	Picture / Format	Vol +	Vol +
>I	>>I / Preset+	TXT	Text / Goto
7	7	<<	<< / Tune-
8	8	Down	Down
9	9	P-	CH- / Page-
?	Smart / List	TV-G	Guide / EPG / -/--
I <	I << / Preset-	>>	>> / Tune+
0	0	Red/ Image/ I >	Red / Netflix / Search
Mute	Mute / Dimmer	Green/ Timer	Green / APP / Repeat

Original	Sustituto	Original	Sustituto
Play	Play / Slow		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		

Original		Sustituto		Original		Sustituto	
	Power		Power		Disc Menu		D.Menu / Top
	1		1		Disc Menu		Menu / Home
	2		2		Up		Up
	3		3		P+		CH+ / Page+
	Audio		Audio / Lang I/II		Left		Left
	4		4		Vol -		Vol -
	5		5		OK		OK
	6		6		Right		Right
	[<>]		Zoom / Size		Vol +		Vol +
	>|		>>| / Preset+		TXT		Text / Goto
	7		7		<<		<< / Tune-
	8		8		Down		Down
	9		9		P-		CH- / Page-
	?		Smart / List		TV-G		Guide / EPG / -/--
	|<		|<< / Preset-		>>		>> / Tune+
	0		0		Red/Picture		Picture / Format
	i/OSD		Display / Media		Red/Picture		Red / Netflix / Search

Original	Sustituto	Original	Sustituto
Green / Timer	Sleep / Timer		
Play	Play / Slow		
Green / Timer	Green / APP / Repeat		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Sound / Title		
Stop	Stop / Hold		
Blue/Sound	Blue / Prime Video / Random		

Original		Sustituto		Original		Sustituto	
	Power		Power		i / OSD		Display / Media
	1		1		Z/Disc Menu		Menu / Home
	2		2		Up		Up
	3		3		P+		CH+ / Page+
	Audio		Audio / Lang I/II		Left		Left
	4		4		Vol -		Vol -
	5		5		OK		OK
	6		6		Right		Right
	[<>]		Zoom / Size		Vol +		Vol +
	>I		>>I / Preset+		TXT		Text / Goto
	7		7		<<		<< / Tune-
	8		8		Down		Down
	9		9		P-		CH- / Page-
	?		Smart / List		TV-G		Guide / EPG / -/--
	I<		I<< / Preset-		>>		>> / Tune+
	0		0		Red/Image/I>		Red / Netflix / Search
	Mute		Mute / Dimmer		Red/Image/I>	+	Shift + Play / Slow

Original	Sustituto	Original	Sustituto
Green/Timer	Green / APP / Repeat		
Play	Play / Slow		
Green/Timer	Sleep / Timer		
Pause	Pause / Step / Freeze		
Yellow/Pause	Yellow / YouTube / Repeat		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		

Original	Sustituto	Original	Sustituto
Power	Power	Z/Disc Menu	Menu / Home
1	1	P+	CH+ / Page+
2	2	Up	Up
3	3	Left	Left
PIP/Audio	Audio / Lang I/II	Vol -	Vol -
4	4	OK	OK
5	5	Right	Right
6	6	Vol +	Vol +
[<>]	Zoom / Size	TXT	Text / Goto
>I	>>I / Preset+	<<	<< / Tune-
7	7	P-	CH- / Page-
8	8	Down	Down
9	9	TV-G	Guide / EPG / -/--
?	Smart / List	>>	>> / Tune+
I<	I<< / Preset-	Red/Image/I>	Picture / Format
0	0	Red/Image/I>	Red / Netflix / Search
i/OSD	Display / Media	Green/Timer	Green / APP / Repeat

Original	Sustituto	Original	Sustituto
Play	Play / Slow		
Green/Timer	Sleep / Timer		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		