Mandis shop

WL-61

Original		Sustituto		Original	Sustituto
START /STOP	Start / Stop		Power		
W	Zoom W	CH PAGE +	CH+ / Page+		
T	Zoom T	CH PAGE −	CH- / Page-		
	Left		Left		
	Up		Up		
	Right		Right		
	Down		Down		
PLAY	Play	SLOW	Play / Slow		
STOP	Stop	HOLD	Stop / Hold		
EXECUTE	Execute	OK	OK		
REW/	<<< / Rew	TUNE-	<< / Tune-		
FF/	>>> / FF	TUNE+	>> / Tune+		
COUNTER RESET	Counter Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze		
ON SCREEN	On Screen	MEDIA DISPLAY	Display / Media		
TAPE RETURN	Tape Return	RETURN BACK	Back / Return		

https://mandisdistance.es/Canon/1604-734-mando-sustituto-para-Canon-WL61.htm