Original	Sustituto	Original	Sustituto
On/Off	Power	Menu	Menu / Home
Mute	Mute / Dimmer	Menu Up	Up
Reveal	Play / Slow	Info	Info / Angle
Store	Pause / Step / Freeze	Menu Left	Left
Txt Stop	Stop / Hold	OK Enter	OK
Tune-	<< / Tune-	Menu Right	Right
Tune+	>> / Tune+	Menu Off	Exit / Cancel / Clear
Update	I << / Preset-	Menu Down	Down
Aft/Caf	>>I / Preset+	Volume+	Vol +
Color- S.Std	Sound / Title	Bright+ Mode	Smart / List
Menu audio	Audio / Lang I/II	Chan. Up	CH+ / Page+
Color+ P.Std	Picture / Format	Volume-	Vol -
Sleep Timer	Sleep / Timer	Display	Display / Media
Return TV	TV/Radio /	Chan. Down	CH- / Page-
Menu video	D.Menu / Top	1	1
Bright- Sys	Setup / OPT /	2	2
TV/AV	AV / Input / RDS	3	3

Original	Sustituto	Original	Sustituto
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
Guide -/-- 1.	Guide / EPG / -/--		
0/10	0		
2. Fav P/C 2.	Fav / Marker / PC		
Search	Red / Netflix / Search		
Yellow	Yellow / YouTube / Repeat		