Mandis shop

RC- P0711

Original		Sustituto	
POWER	Power	POWER	Power
▶/II	Play	SLOW ▶	Play / Slow
▶/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
⏮	I <<	PRESET- ⏮	I << / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format
TIME DISP.	Time Disp.	TIMER SLEEP	Sleep / Timer
OUTPUT UP	Output Up	▲	Up
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
OUTPUT DOWN	Output Down	▼	Down
SKIP	Skip	RETURN BACK	Back / Return
CHECK	Check	LIST SMART	Smart / List
1	1	TV 1	1
2	2	DVD 2	2

Original		Sustituto	
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
EDIT	Edit	PC FAV MARKER	Fav / Marker / PC
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
1	Disc Selector	SHIFT + TV 1	Shift + 1
2	Disc Selector	SHIFT + DVD 2	Shift + 2
3	Disc Selector	SHIFT + CD-STB 3	Shift + 3
4	Disc Selector	SHIFT + VIDEO 4	Shift + 4
5	Disc Selector	SHIFT + TAPE 5	Shift + 5

https://mandisdistribuidores.com/Kenwood/1066889-mandis-sustituto-para-Kenwood-RC-P0711.htm