Original		Sustituto	
	Power		Power
TV/PC	TV/PC	PROGRAM TV/RADIO	TV/Radio /
CAPTION	Caption	EQ SUBTITLE	Subtitle / EQ
AV MODE	AV Mode	SIZE ZOOM	Zoom / Size
RATIO	Ratio	MEDIA DISPLAY	Display / Media
INPUT	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI-SAT 0	0

Original		Sustituto	
FLASHBK	Flashbk	-/-- GUIDE EPG	Guide / EPG / -/--
VOL	Vol +	+ VOL	Vol +
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
CH PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
VOL	Vol -	VOL −	Vol -
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
CH PAGE	CH/Page-	CH PAGE −	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PICTURE	Picture	FORMAT PICTURE	Picture / Format
INFO	Info	ANGLE INFO	Info / Angle
SOUND	Sound	TITLE SOUND	Sound / Title
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
Q.MENU	Q.Menu	TOP MENU D.MENU	D.Menu / Top
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Sustituto		Original		Sustituto	
BACK	Back	RETURN BACK	Back / Return				
▼	Down	▼	Down				
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer				
■	Stop	HOLD ■	Stop / Hold				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
▶	Play	SLOW ▶	Play / Slow				
❚❚	Pause	STEP - FREEZE ❚❚	Pause / Step / Freeze				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
•	Red/ 1	NETFLIX SEARCH	Red / Netflix / Search				
••	Green/ 2	APP REPEAT	Green / APP / Repeat				
∴	Yellow/ 3/ ☼-	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
⁞⁞	Blue/ 4/ ☼+	Prime Video RANDOM	Blue / Prime Video / Random				