Original	Sustituto	Original	Sustituto
Power	Power	Play	Play / Slow
Record	Rec / Rec Mode	Exit	Exit / Cancel / Clear
Mute	Mute / Dimmer	FAV	Fav / Marker / PC
1	1	Stop	Stop / Hold
2	2	Up/ CH+	Up
3	3	Left	Left
4	4	Vol -	Vol -
5	5	OK	OK
6	6	Right	Right
7	7	Vol +	Vol +
8	8	Down/ CH-	Down
9	9	Red	Red / Netflix / Search
Info	Info / Angle	Green	Green / APP / Repeat
0	0	Yellow	Yellow / YouTube / Repeat
Recall	Back / Return	Audio	Audio / Lang I/II
Menu	Menu / Home	Blue	Blue / Prime Video / Random
EPG	Guide / EPG / -/--	Pause	Pause / Step / Freeze

Original		Sustituto		Original	Sustituto
TTX	TTX	GOTO TEXT	Text / Goto		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /		