Original	Sustituto	Original	Sustituto
MENU/PBC PBC	TOP MENU D.MENU D. Menu / Top	10+ 10+	GUIDE EPG Guide / EPG / -/--
LANGUAGE Audio	LANG I/II AUDIO Audio / Lang I/II	DISPLAY Display	MEDIA DISPLAY Display / Media
STANDBY Power	Power	PROG Program	PROGRAM TV/RADIO TV/Radio /
SETUP Setup	OPT-TOOLS SETUP Setup / OPT /	A-B Repeat A-B	YouTube REPEAT A-B Yellow / YouTube / Repeat
Open / Close	SURROUND Eject / Surround	REPEAT Repeat	APP REPEAT Green / APP / Repeat
SUBTITLE Subtitle	EQ SUBTITLE Subtitle / EQ	SLOW Slow	SHIFT + SLOW Shift + Play /
1 1	TV 1 1	GOTO Goto	GOTO TEXT Text / Goto
2 2	DVD 2 2	<<	TUNE- << / Tune-
3 3	CD-STB 3 3	>>	TUNE+ >> / Tune+
4 4	VIDEO 4 4	I <<	PRESET- I << / Preset-
5 5	TAPE 5 5	>>I	PRESET+ >>I / Preset+
6 6	TUNER 6 6	MENU/PBC Menu	HOME MENU Menu / Home
ANGLE Angle	ANGLE INFO Info / Angle	ZOOM Zoom	SIZE ZOOM Zoom / Size
7 7	AUX-HDD 7 7	Up	Up
8 8	USB 8 8	Left	Left
9 9	BLUETOOTH 9 9	ENTER Enter	OK OK
P/N Pal / NTSC	FORMAT PICTURE Picture / Format	Right	Right

Original		Sustituto	
STOP	Stop	HOLD	Stop / Hold
	Down		Down
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow

Original	Sustituto

Original		Sustituto	
STANDBY	Power		Power
	Video SW	HOME MENU	Menu / Home
	Video / PScan	TOP MENU D.MENU	D.Menu / Top
	Open / Close	SURROUND	Eject / Surround
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
LANGUAGE	Language	LANG I/II AUDIO	Audio / Lang I/II
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
ANGLE	Angle	ANGLE INFO	Info / Angle
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
P/N	N/P	PC FAV MARKER	Fav / Marker / PC

Original		Sustituto	
10	0	HDMI-SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
GOTO	Goto	GOTO TEXT	Text / Goto
TITLE	Title	TITLE SOUND	Sound / Title
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
DISPLAY	OSD	MEDIA DISPLAY	Display / Media
SLOW	Slow	SHIFT + SLOW ▶	Shift + Play /
	Step	STEP-FREEZE II	Pause / Step / Freeze
A-B	AB	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
MENU/PBC	PBC	LIST SMART	Smart / List
ZOOM	Zoom	SIZE ZOOM	Zoom / Size

Original	Sustituto	Original	Sustituto
Up	Up		
Left	Left		
Enter	OK		
Right	Right		
Root	Red / Netflix / Search		
Down	Down		
Mute	Mute / Dimmer		
Stop	Stop / Hold		
Play / Pause	Play / Slow		
Vol -	Vol -		
Vol +	Vol +		