| Original | Sustituto |
|---|---|
| Yellow/Info | Yellow / YouTube / Repeat |
| Power | Power |
| Green/[...] | Green / APP / Repeat |
| Blue/Title | Blue / Prime Video / Random |
| Red/Audio | Red / Netflix / Search |
| Up | Up |
| Purple/Camera | Smart / List |
| Left | Left |
| OK | OK |
| Right | Right |
| Down | Down |
| Return | Back / Return |
| Menu | Menu / Home |
| Vol+ | Vol+ |
| +/PR+ | CH+ / Page+ |
| Vol- | Vol- |
| -/PR- | CH- / Page- |

| Original | Sustituto |
|---|---|
| Mute | Mute / Dimmer |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| AV | AV / Input / RDS |
| 0 | 0 |
| << | << / Tune- |
| Play | Play / Slow |
| >> | >> / Tune+ |
| Zoom / Rec | Rec / Rec Mode |
| Zoom / Rec | Zoom / Size |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Stop | Stop / Hold | | |
| Pause | Pause / Step / Freeze | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Sustituto |
|---|---|
| Open/Close | Eject / Surround |
| Yello/Info | Yellow / YouTube / Repeat |
| Yello/Info | Info / Angle |
| Power | Power |
| Marker | Fav / Marker / PC |
| Surround | Shift + Eject / Surround |
| Green/[...] | Green / APP / Repeat |
| Green/[...] | Subtitle / EQ |
| Blue/Title | Blue / Prime Video / Random |
| Blue/Title | Sound / Title |
| Prog/Random | Setup / OPT / |
| Repeat | Shift + Green / APP / |
| Red/Audio | Red / Netflix / Search |
| Up | Up |
| Purple/Camera | Smart / List |
| Purple/Camera | Shift + Info / Angle |
| OO | Display / Media |

| Original | Sustituto |
|---|---|
| Left | Left |
| OK | OK |
| Right | Right |
| Down | Down |
| Return | Back / Return |
| Menu | Menu / Home |
| Vol+ | Vol+ |
| +/PR+/>>I | CH+ / Page+ |
| +/PR+/>>I | >>I / Preset+ |
| Vol- | Vol- |
| -/PR-/I<< | CH- / Page- |
| -/PR-/I<< | I<< / Preset- |
| Mute | Mute / Dimmer |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |

| Original | | Sustituto | |
|---|---|---|---|
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| clear | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| 0 | 0 | HDMI - SAT 0 | 0 |
| REV | << | TUNE- | << / Tune- |
| PLAY | Play | SLOW | Play / Slow |
| FWD | >> | TUNE+ | >> / Tune+ |
| ZOOM REC vcr | Zoom | SIZE ZOOM | Zoom / Size |
| STOP | Stop | HOLD | Stop / Hold |
| PAUSE | Pause | STEP - FREEZE | Pause / Step / Freeze |

| Original | Sustituto |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | | Sustituto | |
|---|---|---|---|
| open/close | Open/Close | SURROUND | Eject / Surround |
| info | Yellow/Info | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Power | | Power |
| marker | Marker | PC FAV MARKER | Fav / Marker / PC |
| | Green/[...] | APP REPEAT | Green / APP / Repeat |
| title | Blue/Title | Prime Video RANDOM | Blue / Prime Video / Random |
| prog/random | Prog/Random | OPT-TOOLS SETUP | Setup / OPT / |
| | Red/Audio | NETFLIX SEARCH | Red / Netflix / Search |
| | Up | | Up |
| | Purple/Camera | LIST SMART | Smart / List |
| | Left | | Left |
| | OK | OK | OK |
| | Right | | Right |
| | OO | MEDIA DISPLAY | Display / Media |
| return | Return | RETURN BACK | Back / Return |
| | Down | | Down |
| menu | Menu | HOME MENU | Menu / Home |

| Original | | Sustituto | |
|---|---|---|---|
| | Vol+ | + VOL | Vol+ |
| pr+ | +/PR+ | + CH PAGE | CH+ / Page+ |
| | Vol- | VOL − | Vol- |
| pr− | -/PR- | CH PAGE − | CH- / Page- |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| clear av | AV | RDS AV INPUT | AV / Input / RDS |
| 0 | 0 | HDMI - SAT 0 | 0 |
| REV | << | TUNE- | << / Tune- |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Play | Play / Slow | | |
| >> | >> / Tune+ | | |
| Rec | Rec / Rec Mode | | |
| Stop | Stop / Hold | | |
| Pause | Pause / Step / Freeze | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |