Original	Sustituto
Yellow/Info	Yellow / YouTube / Repeat
Power	Power
Green/[...]	Green / APP / Repeat
Blue/Title	Blue / Prime Video / Random
Red/Audio	Red / Netflix / Search
Up	Up
Purple/Camera	Smart / List
Left	Left
OK	OK
Right	Right
Down	Down
Return	Back / Return
Menu	Menu / Home
Vol+	Vol+
+/PR+	CH+ / Page+
Vol-	Vol-
-/PR-	CH- / Page-

Original	Sustituto
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
AV	AV / Input / RDS
0	0
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
Zoom / Rec	Rec / Rec Mode
Zoom / Rec	Zoom / Size

Original	Sustituto	Original	Sustituto
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		

Original	Sustituto
Open/Close	Eject / Surround
Yello/Info	Yellow / YouTube / Repeat
Yello/Info	Info / Angle
Power	Power
Marker	Fav / Marker / PC
Surround	Shift + Eject / Surround
Green/[...]	Green / APP / Repeat
Green/[...]	Subtitle / EQ
Blue/Title	Blue / Prime Video / Random
Blue/Title	Sound / Title
Prog/Random	Setup / OPT /
Repeat	Shift + Green / APP /
Red/Audio	Red / Netflix / Search
Up	Up
Purple/Camera	Smart / List
Purple/Camera	Shift + Info / Angle
OO	Display / Media

Original	Sustituto
Left	Left
OK	OK
Right	Right
Down	Down
Return	Back / Return
Menu	Menu / Home
Vol+	Vol+
+/PR+/>>I	CH+ / Page+
+/PR+/>>I	>>I / Preset+
Vol-	Vol-
-/PR-/I<<	CH- / Page-
-/PR-/I<<	I<< / Preset-
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4

Original		Sustituto	
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
clear	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI - SAT 0	0
REV	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
FWD	>>	TUNE+	>> / Tune+
ZOOM REC vcr	Zoom	SIZE ZOOM	Zoom / Size
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze

Original	Sustituto

Original		Sustituto	
open/close	Open/Close	SURROUND	Eject / Surround
info	Yellow/Info	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Power		Power
marker	Marker	PC FAV MARKER	Fav / Marker / PC
	Green/[...]	APP REPEAT	Green / APP / Repeat
title	Blue/Title	Prime Video RANDOM	Blue / Prime Video / Random
prog/random	Prog/Random	OPT-TOOLS SETUP	Setup / OPT /
	Red/Audio	NETFLIX SEARCH	Red / Netflix / Search
	Up		Up
	Purple/Camera	LIST SMART	Smart / List
	Left		Left
	OK	OK	OK
	Right		Right
	OO	MEDIA DISPLAY	Display / Media
return	Return	RETURN BACK	Back / Return
	Down		Down
menu	Menu	HOME MENU	Menu / Home

Original		Sustituto	
	Vol+	+ VOL	Vol+
pr+	+/PR+	+ CH PAGE	CH+ / Page+
	Vol-	VOL −	Vol-
pr−	-/PR-	CH PAGE −	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
clear av	AV	RDS AV INPUT	AV / Input / RDS
0	0	HDMI - SAT 0	0
REV	<<	TUNE-	<< / Tune-

Original	Sustituto	Original	Sustituto
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		