| Original | | Sustituto | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | PIP | | Info / Angle |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [<>] | | Picture / Format |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | Mute | | Mute / Dimmer |

| Original | | Sustituto | |
|---|---|---|---|
| | i / OSD | | Display / Media |
| | Z / Disc Menu | | Menu / Home |
| | Up | | Up |
| | P+ | | CH+ / Page+ |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | Down | | Down |
| | P- | | CH- / Page- |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red / Image / I> | | Red / Netflix / Search |
| | Green / Timer | | Green / APP / Repeat |

| Original | | Sustituto | | Original | Sustituto |
|---|---|---|---|---|---|
| | Play | SLOW | Play / Slow | | |
| | Yellow/Pause | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | Pause | STEP-FREEZE | Pause / Step / Freeze | | |
| | Blue/Sound | Prime Video RANDOM | Blue / Prime Video / Random | | |
| | Stop | HOLD | Stop / Hold | | |
| | Blue/Sound | TITLE SOUND | Sound / Title | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Power | Power | Disc Menu | D.Menu / Top |
| 1 | 1 | Disc Menu | Menu / Home |
| 2 | 2 | Up | Up |
| 3 | 3 | P+ | CH+ / Page+ |
| Audio | Audio / Lang I/II | Left | Left |
| 4 | 4 | Vol - | Vol - |
| 5 | 5 | OK | OK |
| 6 | 6 | Right | Right |
| [<>] | Zoom / Size | Vol + | Vol + |
| >I | >>I / Preset+ | TXT | Text / Goto |
| 7 | 7 | << | << / Tune- |
| 8 | 8 | Down | Down |
| 9 | 9 | P- | CH- / Page- |
| ? | Smart / List | TV-G | Guide / EPG / -/-- |
| I< | I<< / Preset- | >> | >> / Tune+ |
| 0 | 0 | Red/Picture | Picture / Format |
| i/OSD | Display / Media | Red/Picture | Red / Netflix / Search |

| Original | | Sustituto | | Original | Sustituto |
|---|---|---|---|---|---|
| | Green / Timer | | Sleep / Timer | | |
| | Play | | Play / Slow | | |
| | Green / Timer | | Green / APP / Repeat | | |
| | Yellow/Pause | | Yellow / YouTube / Repeat | | |
| | Pause | | Pause / Step / Freeze | | |
| | Blue/Sound | | Sound / Title | | |
| | Stop | | Stop / Hold | | |
| | Blue/Sound | | Blue / Prime Video / Random | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Power | Power | i / OSD | Display / Media |
| 1 | 1 | Z/ Disc Menu | Menu / Home |
| 2 | 2 | Up | Up |
| 3 | 3 | P+ | CH+ / Page+ |
| Audio | Audio / Lang I/II | Left | Left |
| 4 | 4 | Vol - | Vol - |
| 5 | 5 | OK | OK |
| 6 | 6 | Right | Right |
| [<>] | Zoom / Size | Vol + | Vol + |
| >I | >>I / Preset+ | TXT | Text / Goto |
| 7 | 7 | << | << / Tune- |
| 8 | 8 | Down | Down |
| 9 | 9 | P- | CH- / Page- |
| ? | Smart / List | TV-G | Guide / EPG / -/-- |
| I< | I<< / Preset- | >> | >> / Tune+ |
| 0 | 0 | Red/Image/I> | Red / Netflix / Search |
| Mute | Mute / Dimmer | Red/Image/I> | Shift + Play / Slow |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Green/Timer | Green / APP / Repeat | | |
| Play | Play / Slow | | |
| Green/Timer | Sleep / Timer | | |
| Pause | Pause / Step / Freeze | | |
| Yellow/Pause | Yellow / YouTube / Repeat | | |
| Blue/Sound | Blue / Prime Video / Random | | |
| Stop | Stop / Hold | | |
| Blue/Sound | Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Power | Power | Z/Disc Menu | Menu / Home |
| 1 | 1 | P+ | CH+ / Page+ |
| 2 | 2 | Up | Up |
| 3 | 3 | Left | Left |
| PIP/Audio | Audio / Lang I/II | Vol - | Vol - |
| 4 | 4 | OK | OK |
| 5 | 5 | Right | Right |
| 6 | 6 | Vol + | Vol + |
| [<>] | Zoom / Size | TXT | Text / Goto |
| >I | >>I / Preset+ | << | << / Tune- |
| 7 | 7 | P- | CH- / Page- |
| 8 | 8 | Down | Down |
| 9 | 9 | TV-G | Guide / EPG / -/-- |
| ? | Smart / List | >> | >> / Tune+ |
| I< | I<< / Preset- | Red/Image/I> | Picture / Format |
| 0 | 0 | Red/Image/I> | Red / Netflix / Search |
| i/OSD | Display / Media | Green/Timer | Green / APP / Repeat |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Play | SLOW Play / Slow | | |
| Green/Timer | TIMER SLEEP Sleep / Timer | | |
| Yellow/Pause | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| Pause | STEP-FREEZE Pause / Step / Freeze | | |
| Blue/Sound | Prime Video RANDOM Blue / Prime Video / Random | | |
| Stop | HOLD Stop / Hold | | |
| Blue/Sound | TITLE SOUND Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |