Original	Sustituto
TIMER Timer	SHIFT + TIMER SLEEP Shift + Sleep / Timer
SLEEP Sleep	TIMER SLEEP Sleep / Timer
CLOCK Clock	OPT-TOOLS SETUP Setup / OPT /
EDIT/REMAIN Edit/Remain	SIZE ZOOM Zoom / Size
PRGM PRGM	PROGRAM TV/RADIO TV/Radio /
RANDOM Random	SHIFT + Prime Video RANDOM Shift + Blue / Prime
REPEAT MONO TUNER Repeat / Mono	SHIFT + APP REPEAT Shift + Green / APP /
DISC DIRECT PLAY 1 Disc Direct Play 1	Left
DISC DIRECT PLAY 2 Disc Direct Play 2	Up
DISC DIRECT PLAY 3 Disc Direct Play 3	Right
OPEN/CLOSE Open/Close	SURROUND Eject / Surround
1 1	TV 1 1
2 2	DVD 2 2
3 3	CD-STB 3 3
4 4	VIDEO 4 4
5 5	TAPE 5 5
6 6	TUNER 6 6

Original	Sustituto
7 7	AUX-HDD 7 7
8 8	USB 8 8
9 9	BLUETOOTH 9 9
0 0	HDMI-SAT 0 0
+10 +10	-/-- GUIDE EPG Guide / EPG / -/--
BBE BBE	LANG I/II AUDIO Audio / Lang I/II
MANU GEQ GEQ MANU	CH PAGE − CH- / Page-
KARAOKE Karaoke	GOTO TEXT Text / Goto
T-BASS T-Bass	TITLE SOUND Sound / Title
GEQ PRGM GEQ PRGM	+ CH PAGE CH+ / Page+
GEQ PRGM GEQ PRGM	EQ SUBTITLE Subtitle / EQ
DSP PRGM DSP PRGM	LIST SMART Smart / List
CD CD	NETFLIX SEARCH Red / Netflix / Search
CD CD	SHIFT + CD-STB 3 Shift + 3
<> Direction	SLOW ▶ Play / Slow
VIDEO/AUX Video/AUX	SHIFT + VIDEO 4 Shift + 4
VIDEO/AUX Video/AUX	APP REPEAT Green / APP / Repeat

Original	Sustituto	Original	Sustituto
Video/AUX	SHIFT + AUX-HDD 7 — Shift + 7		
I<</Down/<<	TUNE- — << / Tune-		
I<</Down/<<	PRESET- — I<< / Preset-		
>>/Up/>>I	PRESET+ — >>I / Preset+		
>>/Up/>>I	TUNE+ — >> / Tune+		
Tuner/Band	YouTube / REPEAT A-B — Yellow / YouTube / Repeat		
Tuner/Band	SHIFT + TUNER 6 — Shift + 6		
Rec/Rec Mute	REC MODE — Rec / Rec Mode		
Stop	HOLD — Stop / Hold		
Pause	STEP-FREEZE — Pause / Step / Freeze		
Tape/Deck 1/2	SHIFT + TAPE 5 — Shift + 5		
Tape/Deck 1/2	Prime Video / RANDOM — Blue / Prime Video / Random		
Power	Power		
Volume Down	VOL − — Vol-		
Volume Up	VOL + — Vol+		