Original	Sustituto	Original	Sustituto
Power	Power	Vol +	Vol +
Sleep	Sleep	Vol -	Vol -
CBL/SAT	1	Eco	3D
DVD	2	Info	Info
Blu-ray	3	Option	Options
Game	4	Back	Back
AUX	5	Setup	Menu
Media Player	6	Enter	Ok
USB	7	Up	Up
TV Audio	8	Down	Down
Tuner	9	Right	Right
.:l:.	Guide	Left	Left
Bluetooth	0	Play	Play
Internet Radio	Pre Ch	Pause	Pause
Mute	Mute	I<</Tune-	I<<
CH/Page+	Ch +	>>I/Tune+	>>I
CH/Page-	Ch -	Green/Movie	Green

Original		Sustituto	
MUSIC	Red/ Music	A	Red
GAME	Blue/ Game	D	Blue
PURE	Yellow/ Pure	C	Yellow
1	Quick Select 1	E-MANUAL D.MENU	D. Menu
2	Quick Select 2	REPEAT TEXT	Text
3	Quick Select 3	ZOOM	Eject
4	Quick Select 4	TIMER AV	AV

Original	Sustituto

Original	Sustituto	Original	Sustituto
Power	Power	Vol -	Vol -
Sleep	Sleep	Mute	Mute
CBL/SAT	1	Back	Back
DVD	2	Enter	Ok
Blu-ray	3	Up	Up
Game	4	Down	Down
AUX	5	Left	Left
Media Player	6	Right	Right
USB	7	Play	Play
TV Audio	8	Pause	Pause
Tuner	9	I <</ Tune-	I <<
. : I : .	Guide	>>I / Tune+	>>I
Bluetooth	0	Quick Select 1	D. Menu
Internet Radio	Pre Ch	Quick Select 4	AV
CH/ Page+	Ch +	Quick Select 3	Eject
CH/ Page-	Ch -	Quick Select 2	Text
Vol +	Vol +		