Mandis shop

Denon RC-824

Original		Sustituto	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
TUNING UP	Tuning Up	+ CH	Ch +
DOWN	Tuning Down	CH −	Ch -
	No name	CLEAR EXIT	Exit
SEARCH/ CHARACTER	Search/Character	SEARCH TV/R	TV/R
DISPLAY	Display	DISPLAY INFO	Info
SHIFT/PTY	Shift/PTY	SETTINGS OPT	Options
MEMORY	Memory	APP MEDIA	Media
AUTO/ MANU	Auto/Manu	RETURN BACK	Back

Original		Sustituto	
BAND	Band	HOME SMART	Smart