Original	Sustituto	Original	Sustituto
Off	SHIFT + Power	V. Sel	Picture / Format
Power	Power	Sleep	Sleep / Timer
Quick Select 1 (DVD)	SHIFT + 1	Multi EQ	Green / APP / Repeat
Quick Select 2 (SAT/CBL)	SHIFT + 2	Dyn EQ	Yellow / YouTube / Repeat
Quick Select 3 (VCR/iPod)	SHIFT + 3	Dyn Vol	Blue / Prime Video / Random
TV	1	Mute	Mute / Dimmer
TUNER	6	Menu	Menu / Home
V.AUX	7	CH. Level	D. Menu / Top
DVD	2	Volume+	Vol +
HDP	3	Up	Up
iPod	8	Left	Left
Speakers	Eject / Surround	Enter	OK
DVR	5	Right	Right
VCR	4	Down	Down
SAT/CBL	0	Volume-	Vol -
Input Mode	SHIFT + AV / Input / RDS	Setup	Setup / OPT /
Source Select	AV / Input / RDS	Search	Red / Netflix / Search

Original	Sustituto	Original	Sustituto
RETURN Return	RETURN BACK Back / Return	MUSIC Music	EQ SUBTITLE Subtitle / EQ
SKIP+ MEMORY Memory	REC MODE Rec / Rec Mode	SIMU Simu	LIST SMART Smart / List
BAND Band	HOLD Stop / Hold	RESTORER Restorer	MEDIA DISPLAY Display / Media
SHIFT Shift	STEP-FREEZE Pause / Step / Freeze		
MODE Mode	SLOW Play / Slow		
TUNING Tun-	SHIFT + TUNE- Shift + << /		
TUNING Tuning-	TUNE- << / Tune-		
TUNING Tun+	SHIFT + TUNE+ Shift + >> /		
TUNING Tuning+	TUNE+ >> / Tune+		
CHANN Preset-	PRESET- I << / Preset-		
CHANN Channel -	CH PAGE CH- / Page-		
CHANNEL Preset +	PRESET+ >>I / Preset +		
CHANNEL Channel +	CH PAGE CH+ / Page+		
STD STD	TITLE SOUND Sound / Title		
PAGE DIMMER Dimmer	SHIFT + DIMMER MUTE Shift + Mute / Dimmer		
PAGE STATUS Status	ANGLE INFO Info / Angle		
CINEMA Cinema	LANG I/II AUDIO Audio / Lang I/II		

Original		Sustituto		Original		Sustituto	
MENU	Menu	HOME MENU	Menu / Home				
	Up		Up				
	Left		Left				
ENTER	Enter	OK	OK				
	Right		Right				
	Down		Down				
SKIP+ MEMORY	Skip+	LIST SMART	Smart / List				
BAND	Stop	HOLD	Stop / Hold				
SHIFT	Pause	STEP-FREEZE	Pause / Step / Freeze				
MODE	Play	SLOW	Play / Slow				
TUNING	<<	TUNE-	<< / Tune-				
TUNING	>>	TUNE+	>> / Tune+				
CHANN	I <<	PRESET-	I << / Preset-				
CHANNEL +	>>I	PRESET+	>>I / Preset+				