Original		Sustituto	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
VOL+	Vol +	+ VOL	Vol +
VOL-	Vol -	VOL −	Vol -
TV/R	TV/ R	PROGRAM TV/ RADIO	TV/ Radio /
PAGE+	Page+	+ CH PAGE	CH+ / Page+
PAGE-	Page-	CH PAGE −	CH- / Page-

Original		Sustituto	
IPTV	IPTV	LIST SMART	Smart / List
VOD	VOD	MEDIA DISPLAY	Display / Media
INFO	Info	ANGLE INFO	Info / Angle
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
RECALL	Recall	RETURN BACK	Back / Return
	Up		Up
	Down		Down
OK	OK	OK	OK
	Right		Right
	Left		Left
YOUTUBE	Red/ YouTube	NETFLIX SEARCH	Red / Netflix / Search
YOUTUBE	Red/ YouTube	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
QURAN	Blue/ Quran	Prime Video RANDOM	Blue / Prime Video / Random
TTX/CC	TTX/ CC	GOTO TEXT	Text / Goto

Original		Sustituto		Original	Sustituto
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
FAV	FAV	PC FAV MARKER	Fav / Marker / PC		
SOURCE	Source	RDS AV INPUT	AV / Input / RDS		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
SUB	SUB	EQ SUBTITLE	Subtitle / EQ		
FILELIST	Filelist	SHIFT + LIST SMART	Shift + Smart / List		
FILELIST	Filelist	FORMAT PICTURE	Picture / Format		
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0		
SAT	SAT	OPT-TOOLS SETUP	Setup / OPT /		
<<	<<	TUNE- <<	<< / Tune-		
>>	>>	TUNE+ >>	>> / Tune+		
Play	Play	SLOW Play	Play / Slow		
Pause	Pause	STEP-FREEZE Pause	Pause / Step / Freeze		
I<<	I<<	PRESET- I<<	I<< / Preset-		
>>I	>>I	PRESET+ >>I	>>I / Preset+		
Stop	Stop	HOLD Stop	Stop / Hold		
TIMESHIFT	Rec/Timeshift	REC MODE Rec	Rec / Rec Mode		

Original	Sustituto	Original	Sustituto
Power	Power	Audio	Audio / Lang I/II
Mute	Mute / Dimmer	EPG	Guide / EPG / -/--
<<	<< / Tune-	i	Info / Angle
Green/VOD	Green / APP / Repeat	Menu	Menu / Home
Yellow/YouTube	Yellow / YouTube / Repeat	Exit	Exit / Cancel / Clear
Blue/Quran	Blue / Prime Video / Random	FAV	Fav / Marker / PC
Red/IPTV	Red / Netflix / Search	Rec	Rec / Rec Mode
>>	>> / Tune+	Up	Up
I <<	I << / Preset-	OK	OK
>>I	>>I / Preset+	Down	Down
Play	Play / Slow	Right	Right
Pause	Pause / Step / Freeze	Left	Left
Stop	Stop / Hold	Vol +	Vol +
SAT	SHIFT + 9 / Shift + 9	Vol -	Vol -
Media	Display / Media	Page+	CH+ / Page+
Timer	Sleep / Timer	Page-	CH- / Page-
Recall	Back / Return	1	1

Original	Sustituto		Original	Sustituto
2	DVD 2	2		
3	CD - STB 3	3		
4	VIDEO 4	4		
5	TAPE 5	5		
6	TUNER 6	6		
7	AUX - HDD 7	7		
8	USB 8	8		
9	BLUETOOTH 9	9		
0	HDMI - SAT 0	0		
Subtitle	EQ SUBTITLE	Subtitle / EQ		
Tv/ Radio	PROGRAM TV/ RADIO	TV/ Radio /		