Mandis shop

F. E. T. TP711

Original		Sustituto	
1	1	1	1
2	2	2	2
3	3	3	3
Power	Power	Power	Power
4	4	4	4
5	5	5	5
6	6	6	6
Brightness+	>>I / Preset+	PRESET+	>>I / Preset+
7	7	7	7
8	8	8	8
9	9	9	9
Brightness-	I<< / Preset-	PRESET-	I<< / Preset-
PC/AUX	AV / Input / RDS	RDS AV INPUT	AV / Input / RDS
0/AV	0/AV	0	0
TXT	Text / Goto	GOTO TEXT	Text / Goto
Color+	>> / Tune+	TUNE+	>> / Tune+
P+	CH+ / Page+	CH PAGE	CH+ / Page+

Original		Sustituto	
P+	Up		Up
Color-	<< / Tune-	TUNE-	<< / Tune-
Left	Left		Left
Vol -	Vol -	VOL	Vol -
OK	OK	OK	OK
Right	Right		Right
Vol +	Vol +	VOL	Vol +
i	Info / Angle	ANGLE INFO	Info / Angle
Down	Down		Down
P-	CH- / Page-	CH PAGE	CH- / Page-
Mute	Mute / Dimmer	DIMMER MUTE	Mute / Dimmer

https://mandisadstaticas/es/F.E.T./1059162209-mando-sustituto-para-F.E.T.-TP711.htm