Original		Sustituto	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
QUALITY/P-	Quality/P-	CH PAGE −	CH- / Page-
0	0	HDMI - SAT 0	0
RECALL/P+	Recall/P+	+ CH PAGE	CH+ / Page+
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up

Original		Sustituto	
	Left		Left
OK	OK	OK	OK
	Right		Right
SEL	Sel	LIST SMART	Smart / List
	Down		Down
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
PAUSE	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
SUBTITLE	Red/Subtitle	NETFLIX SEARCH	Red / Netflix / Search
AV	AV	RDS AV INPUT	AV / Input / RDS
TV/R	TV/R	PROGRAM TV/ RADIO	TV/Radio /
INFO	Blue/Info	Prime Video RANDOM	Blue / Prime Video / Random
PIP	Green/PIP	APP REPEAT	Green / APP / Repeat
EPG	Yellow/EPG	YouTube REPEAT A-B	Yellow / YouTube / Repeat