Mandis shop

JVC RMMH9G

Original		Sustituto	
ON	On		Power
STAND BY	Standby	SHIFT +	Shift + Power
HDMI 1	HDMI 1	TV 1	1
HDMI 2	HDMI 2	DVD 2	2
COMP.	Comp.	CD - STB 3	3
VIDEO	Video	VIDEO 4	4
S-VIDEO	S-Video	TAPE 5	5
PC	PC	PC FAV MARKER	Fav / Marker / PC
PC	PC	TUNER 6	6
LENS	Lens	SIZE ZOOM	Zoom / Size
HIDE	Hide	TIMER SLEEP	Sleep / Timer
ASPECT	Aspect	FORMAT PICTURE	Picture / Format
TEST	Test	GOTO TEXT	Text / Goto
▲	Up		Up
◄	Left		Left
OK	OK	OK	OK
►	Right		Right

Original		Sustituto	
▼	Down		Down
MENU	Menu	HOME MENU	Menu / Home
BACK	Back	RETURN BACK	Back / Return
CINEMA 1	Cinema 1	SHIFT + TV 1	Shift + 1
CINEMA 2	Cinema 2	SHIFT + DVD 2	Shift + 2
CINEMA 3	Cinema 3	SHIFT + CD - STB 3	Shift + 3
NATURAL	Natural	SHIFT + VIDEO 4	Shift + 4
STAGE	Stage	SHIFT + TAPE 5	Shift + 5
DYNAMIC	Dynamic	SHIFT + TUNER 6	Shift + 6
USER 1	User 1	SHIFT + AUX - HDD 7	Shift + 7
USER 2	User 2	SHIFT + USB 8	Shift + 8
THX	THX	SHIFT + BLUETOOTH 9	Shift + 9
GAMMA	Gamma	NETFLIX SEARCH	Red / Netflix / Search
C.TEMP	C.Temp	APP REPEAT	Green / APP / Repeat
LENS AP.	Lens AP.	YouTube REPEAT A-B	Yellow / YouTube / Repeat
PIC. ADJ.	Pic. Adj.	Prime Video RANDOM	Blue / Prime Video / Random

https://mandos-a-distancia.es/es/JVC/1061629-12530-mando-de-sustitucion-para-JVC-RMMH9G.html