Original		Sustituto	
	Power		Power
TV/RAD	TV/Radio	PROGRAM TV/RADIO	TV/Radio /
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AV MODE	AV Mode	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
RATIO	Ratio	FORMAT PICTURE	Picture / Format
INPUT	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI-SAT 0	0

Original		Sustituto	
Q.VIEW	Q. View	MEDIA DISPLAY	Display / Media
	Vol +	+ VOL	Vol +
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
P PAGE	PR+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
P PAGE	PR-	CH PAGE −	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TEXT	Text	GOTO TEXT	Text / Goto
INFO	Info	ANGLE INFO	Info / Angle
T.OPT	T. Opt	TOP MENU D.MENU	D. Menu / Top
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
Q.MENU	Q. Menu	HOME MENU	Menu / Home
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Sustituto		Original	Sustituto
BACK	Back	RETURN BACK	Back / Return		
▼	Down	▼	Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
SIMPLINK	Simplink	SIZE ZOOM	Zoom / Size		
AD	AD	LANG I/II AUDIO	Audio / Lang I/II		
■	Stop	HOLD ■	Stop / Hold		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶	Play	SLOW ▶	Play / Slow		
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
●	Red	NETFLIX SEARCH	Red / Netflix / Search		
●●	Green	APP REPEAT	Green / APP / Repeat		
●●	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
●●	Blue	Prime Video RANDOM	Blue / Prime Video / Random		