Original		Sustituto	
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	TV/Radio		TV/Radio /
	0		0
	EPG		Guide / EPG / -/--
	Fav		Fav / Marker / PC
	Menu		Menu / Home
	Info		Info / Angle

Original		Sustituto	
	Pause		Pause / Step / Freeze
	Exit		Exit / Cancel / Clear
	SAT		Shift + 0
	V-Mode		Display / Media
	TV/AV		AV / Input / RDS
	Sleep		Sleep / Timer
	Up / PR+		CH+ / Page+
	Up / PR+		Up
	Left / Vol-		Left
	Left / Vol-		Vol-
	OK / List		OK
	OK / List		Smart / List
	Right / Vol+		Vol+
	Right / Vol+		Right
	Page-		Shift + CH- /
	Down / PR-		CH- / Page-
	Down / PR-		Down

Original		Sustituto		Original	Sustituto
PAGE+	Page+	SHIFT + CH PAGE	Shift + CH+ /		
FIND	Red / Find	NETFLIX SEARCH	Red / Netflix / Search		
V-FORMAT	Green / V-Format	FORMAT PICTURE	Picture / Format		
V-FORMAT	Green / V-Format	APP REPEAT	Green / APP / Repeat		
TXT	Yellow / TXT	GOTO TEXT	Text / Goto		
TXT	Yellow / TXT	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue / Audio L/R	LANG I/II AUDIO	Audio / Lang I/II		
	Blue / Audio L/R	Prime Video RANDOM	Blue / Prime Video / Random		
RECORD	Record	REC MODE	Rec / Rec Mode		
PLAY	Play	SLOW	Play / Slow		
STOP	Stop	HOLD	Stop / Hold		
SHIFT	Shift	SURROUND	Eject / Surround		
FAST	<< Fast	TUNE-	<< / Tune-		
AST	Fast >>	TUNE+	>> / Tune+		
SLO	< Slow	PRESET-	I<< / Preset-		
LOW	Slow >	PRESET+	>>I / Preset+		