Original		Sustituto	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TFT ON/OFF	TFT On/Off		Power
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
ANGLE	Angle	ANGLE INFO	Info / Angle
DVD/USB/CARD	DVD/USB/Card	SHIFT + DVD 2	Shift + 2
OSD	OSD	MEDIA DISPLAY	Display / Media
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
TITLE	Title	TITLE SOUND	Sound / Title
	Left		Left
OK	OK	OK	OK
	Right		Right
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
	Down		Down

Original		Sustituto	
VOL +	Vol +	VOL +	Vol +
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
VOL -	Vol -	VOL -	Vol -
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PROGRAM	Program	PROGRAM TV/ RADIO	TV/ Radio /
0/10	0/10	HDMI - SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
STOP	Stop	HOLD	Stop / Hold
PLAY/PAUSE	Play	SLOW	Play / Slow

Original		Sustituto	
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PREV	I <</ Prev	PRESET-	I << / Preset-
NEXT	>>I / Next	PRESET+	>>I / Preset+
REV	<</ REV	TUNE-	<< / Tune-
FWD	>>/ FWD	TUNE+	>> / Tune+

Original	Sustituto