Original		Sustituto	
	Power		Power
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
V+	Vol +	VOL +	Vol +
V-	Vol -	VOL −	Vol -
P+	PR+	CH +	Ch +
P-	PR-	CH −	Ch -
EXIT	Exit	CLEAR EXIT	Exit
BACK	Back	RETURN BACK	Back
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
INFO	Info	DISPLAY INFO	Info

Original		Sustituto	
MENU	Menu	TOP MENU MENU	Menu
	Mute	MUTE	Mute
SOURCE	Source	TIMER AV	AV
SWAP	Swap	FAV PRE-CH	Pre Ch
0	0	0	0
1	1	1	1
2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9
EPG	EPG	-/-- GUIDE	Guide
TEXT	Text	REPEAT TEXT	Text
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch

Original		Sustituto	
SLEEP	Sleep	PROG SLEEP	Sleep
SUBTITLE	Subtitle	AD SUBT	Subt
LANG	Lang	SOUND DUAL	Dual
SCREEN	Screen	PICTURE FORMAT	Format
PRESETS	Presets	ZOOM	Eject
INTERNET	Internet	HOME SMART	Smart
MULTIMEDIA	Multimedia	APP MEDIA	Media
▶	Play	PLAY MODE ▶	Play
MY BUTTON 1	My Button1	DISC NAV LIST	List
MY BUTTON 2	My Button2	E-MANUAL D.MENU	D. Menu
●	Rec	REC MODE ●	Rec
❚❚	Pause	❚❚	Pause
■	Stop	■	Stop
▶▶	>>	≫	>>
◀◀	<<	≪	<<
▶▶❚	>>I	≫❚	>>I
❚◀◀	I <<	❚≪	I <<

Original	Sustituto