| Original | | Sustituto | |
|---|---|---|---|
| ON/STANDBY | On / Standby | | Power |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| BD/DVD | Input BD/DVD | SHIFT + DVD 2 | Shift + 2 |
| VCR/DVR | Input VCR/DVR | SHIFT + VIDEO 4 | Shift + 4 |
| CBL/SAT | Input CBL/SAT | SHIFT + HDMI - SAT 0 | Shift + 0 |
| GAME | Input Game | SHIFT + TAPE 5 | Shift + 5 |
| AUX | Input AUX | SHIFT + AUX - HDD 7 | Shift + 7 |
| TUNER | Input Tuner | SHIFT + TUNER 6 | Shift + 6 |
| TV/CD | Input TV/CD | SHIFT + TV 1 | Shift + 1 |
| TV/CD | Input TV/CD | SHIFT + CD - STB 3 | Shift + 3 |
| PORT | Input Port | SHIFT + USB 8 | Shift + 8 |
| TUN MODE | Tun Mode | LIST SMART | Smart / List |
| MUTING | Muting | DIMMER MUTE | Mute / Dimmer |
| + | Tone + | SHIFT + TUNE+ ▶▶ | Shift + >> / |
| CH + | CH + | CH PAGE + | CH+ / Page+ |
| VOL + | Vol + | VOL + | Vol + |
| − | Tone | GOTO TEXT | Text / Goto |

| Original | | Sustituto | |
|---|---|---|---|
| − | Tone - | SHIFT + TUNE- ◀◀ | Shift + << / |
| CH − | CH - | CH PAGE − | CH- / Page- |
| VOL | Vol - | VOL − | Vol - |
| GUIDE/TOP MENU SP A/B | Guide / Top Menu | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| GUIDE/TOP MENU SP A/B | Guide / Top Menu | TOP MENU D.MENU | D. Menu / Top |
| | Up | ▲ | Up |
| PREV CH/MENU | Prev CH / Menu | HOME MENU | Menu / Home |
| PREV CH/MENU | Prev CH / Menu | PC FAV MARKER | Fav / Marker / PC |
| PLAYLIST /CATEGORY | Left / Playlist/Category | ◀ | Left |
| ENTER | Enter | OK | OK |
| PLAYLIST /CATEGORY | Right / Playlist/Category | ▶ | Right |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| | Down | ▼ | Down |
| RETURN | Return | RETURN BACK | Back / Return |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| ◀◀ | I << | PRESET- ◀◀ | I << / Preset- |
| ▶▶ | >>I | PRESET+ ▶▶ | >>I / Preset+ |

| Original | | Sustituto | |
|---|---|---|---|
| | << | TUNE- << | << / Tune- |
| | Play | SLOW ▶ | Play / Slow |
| | >> | TUNE+ >> | >> / Tune+ |
| | Pause / Play Reverse | STEP-FREEZE ⏸ | Pause / Step / Freeze |
| | Stop | HOLD ■ | Stop / Hold |
| MOVIE/TV SEARCH | Movie/TV / Searc | NETFLIX SEARCH | Red / Netflix / Search |
| MOVIE/TV SEARCH | Movie/TV / Searc | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| MUSIC REPEAT | Music / Repeat | APP REPEAT | Green / APP / Repeat |
| MUSIC REPEAT | Music / Repeat | SHIFT + APP REPEAT | Shift + Green / APP / |
| GAME RANDOM | Game / Random | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| GAME RANDOM | Game / Random | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| STEREO PLAY MODE | Stereo / Play | TITLE SOUND | Sound / Title |
| STEREO PLAY MODE | Stereo / Play | Prime Video RANDOM | Blue / Prime Video / Random |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |

| Original | | Sustituto | |
|---|---|---|---|
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| +10 D.TUN DIMMER | +10 / Dimmer | -/-- GUIDE EPG | Guide / EPG / -/-- |
| +10 D.TUN DIMMER | D.Tun Tuner | ANGLE INFO | Info / Angle |
| +10 D.TUN DIMMER | +10 / Dimmer | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer |
| 0 | 0 | HDMI-SAT 0 | 0 |
| CLR SLEEP | Clear / Sleep | TIMER SLEEP | Sleep / Timer |
| CLR SLEEP | Clear / Sleep | CLEAR EXIT CANCEL | Exit / Cancel / Clear |

| Original | Sustituto |
|---|---|
| On/Standby | Power |
| On/Standby | Shift + Power |
| Display BD/DVD | Display / Media |
| Input BD/DVD | Shift + 2 |
| Input VCR/DVR | Shift + 4 |
| Input CBL/SAT | Shift + 0 |
| Input Game | Shift + 5 |
| Input AUX | Shift + 7 |
| Input Tuner | Shift + 6 |
| Input TV/CD | Shift + 1 |
| Input TV/CD | Shift + 3 |
| Input Port | Shift + 8 |
| Tone | Text / Goto |
| Tun Mode | Smart / List |
| Muting | Mute / Dimmer |
| Tone + | Shift + >> / |
| Vol + | Vol + |

| Original | Sustituto |
|---|---|
| Tone - | Shift + << / |
| Vol - | Vol - |
| Guide / Top Menu BD/DVD | D.Menu / Top |
| Guide / Top Menu BD/DVD | Shift + Guide / EPG / -/-- |
| Up BD/DVD | Up |
| Prev CH / Menu BD/DVD | Fav / Marker / PC |
| Prev CH / Menu BD/DVD | Menu / Home |
| Left / Playlist/Category | Left |
| Enter BD/DVD | OK |
| Right / Playlist/Category | Right |
| Setup BD/DVD | Setup / OPT / |
| Down BD/DVD | Down |
| Return BD/DVD | Back / Return |
| Audio BD/DVD | Audio / Lang I/II |
| I<< BD/DVD | I<< / Preset- |
| >>I BD/DVD | >>I / Preset+ |
| << BD/DVD | << / Tune- |

| Original | | Sustituto | |
|---|---|---|---|
| | Play BD/DVD | SLOW | Play / Slow |
| | >> BD/DVD | TUNE+ | >> / Tune+ |
| | Pause BD/DVD | STEP-FREEZE | Pause / Step / Freeze |
| | Stop BD/DVD | HOLD | Stop / Hold |
| MOVIE/TV SEARCH | Movie/TV / Search BD/DVD | NETFLIX SEARCH | Red / Netflix / Search |
| MOVIE/TV SEARCH | Movie/TV / Search BD/DVD | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| MUSIC REPEAT | Music / Repeat BD/DVD | APP REPEAT | Green / APP / Repeat |
| MUSIC REPEAT | Music / Repeat BD/DVD | SHIFT + APP REPEAT | Shift + Green / APP / |
| GAME RANDOM | Game / Random BD/DVD | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| GAME RANDOM | Game / Random BD/DVD | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| STEREO PLAY MODE | Stereo / Play Mode BD/DVD | Prime Video RANDOM | Blue / Prime Video / Random |
| 1 | 1 BD/DVD | TV 1 | 1 |
| 2 | 2 BD/DVD | DVD 2 | 2 |
| 3 | 3 BD/DVD | CD-STB 3 | 3 |
| 4 | 4 BD/DVD | VIDEO 4 | 4 |
| 5 | 5 BD/DVD | TAPE 5 | 5 |
| 6 | 6 BD/DVD | TUNER 6 | 6 |

| Original | | Sustituto | |
|---|---|---|---|
| 7 | 7 BD/DVD | AUX-HDD 7 | 7 |
| 8 | 8 BD/DVD | USB 8 | 8 |
| 9 | 9 BD/DVD | BLUETOOTH 9 | 9 |
| +10 D.TUN DIMMER | +10 / Dimmer | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 BD/DVD | HDMI-SAT 0 | 0 |
| CLR SLEEP | CLR / Sleep | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| CLR SLEEP | CLR / Sleep | TIMER SLEEP | Sleep / Timer |

| Original | | Sustituto | |
|---|---|---|---|
| ON/STANDBY | On / Standby | | Power |
| ON/STANDBY | On / Standby | SHIFT + | Shift + Power |
| DISPLAY | Display TV/CD | MEDIA DISPLAY | Display / Media |
| BD/DVD | Input BD/DVD | SHIFT + DVD 2 | Shift + 2 |
| VCR/DVR | Input VCR/DVR | SHIFT + VIDEO 4 | Shift + 4 |
| CBL/SAT | Input CBL/SAT | SHIFT + HDMI - SAT 0 | Shift + 0 |
| GAME | Input Game | SHIFT + TAPE 5 | Shift + 5 |
| AUX | Input Aux | SHIFT + AUX - HDD 7 | Shift + 7 |
| TUNER | Input Tuner | SHIFT + TUNER 6 | Shift + 6 |
| TV/CD | Input TV/CD | SHIFT + TV 1 | Shift + 1 |
| TV/CD | Input TV/CD | SHIFT + CD - STB 3 | Shift + 3 |
| PORT | Input Port | SHIFT + USB 8 | Shift + 8 |
| TUN MODE | Tun Mode | LIST SMART | Smart / List |
| MUTING | Muting | DIMMER MUTE | Mute / Dimmer |
| + | Tone + | SHIFT + TUNE+ | Shift + >> / |
| + DISC ALBUM | Disc + / Album + TV/CD | + CH PAGE | CH+ / Page+ |
| VOL | Vol + | + VOL | Vol + |

| Original | | Sustituto | |
|---|---|---|---|
| – | Tone | GOTO TEXT | Text / Goto |
| – | Tone - | SHIFT + TUNE- | Shift + << / |
| DISC ALBUM – | Disc - / Album TV/CD | CH PAGE – | CH- / Page- |
| VOL | Vol - | VOL – | Vol - |
| | Up TV/CD | | Up |
| PLAYLIST /CATEGORY | Left / Playlist/Category | | Left |
| ENTER | Enter TV/CD | OK | OK |
| PLAYLIST /CATEGORY | Right / Playlist/Category | | Right |
| SETUP | Setup TV/CD | OPT-TOOLS SETUP | Setup / OPT / |
| | Down TV/CD | | Down |
| RETURN | Return TV/CD | RETURN BACK | Back / Return |
| AUDIO | Audio TV/CD | LANG I/II AUDIO | Audio / Lang I/II |
| | I<< TV/CD | PRESET- | I<< / Preset- |
| | >>I TV/CD | PRESET+ | >>I / Preset+ |
| | << TV/CD | TUNE- | << / Tune- |
| | Play TV/CD | SLOW | Play / Slow |
| | >> TV/CD | TUNE+ | >> / Tune+ |

| Original | Sustituto |
|---|---|
| Pause TV/CD | Pause / Step / Freeze |
| Stop TV/CD | Stop / Hold |
| Movie/TV / Search TV/CD | Red / Netflix / Search |
| Movie/TV / Search TV/CD | Shift + Red / Netflix / |
| Music / Repeat TV/CD | Green / APP / Repeat |
| Music / Repeat TV/CD | Shift + Green / APP / |
| Game / Random | Shift + Blue / Prime |
| Game / Random | Yellow / YouTube / Repeat |
| Stereo / Play Mode TV/CD | Blue / Prime Video / Random |
| 1 TV/CD | 1 |
| 2 TV/CD | 2 |
| 3 TV/CD | 3 |
| 4 TV/CD | 4 |
| 5 TV/CD | 5 |
| 6 TV/CD | 6 |
| 7 TV/CD | 7 |
| 8 TV/CD | 8 |

| Original | Sustituto |
|---|---|
| 9 TV/CD | 9 |
| +10 / Dimmer | Guide / EPG / -/-- |
| 0 TV/CD | 0 |
| CLR / Sleep TV/C | Exit / Cancel / Clear |
| CLR / Sleep TV/C | Sleep / Timer |

| Original | | Sustituto | |
|---|---|---|---|
| ON/STANDBY | On / Standby | | Power |
| ON/STANDBY | On / Standby Por | SHIFT + | Shift + Power |
| DISPLAY | Display Port | MEDIA DISPLAY | Display / Media |
| BD/DVD | Input BD/DVD | SHIFT + DVD 2 | Shift + 2 |
| VCR/DVR | Input VCR/DVR | SHIFT + VIDEO 4 | Shift + 4 |
| CBL/SAT | Input CBL/SAT | SHIFT + HDMI - SAT 0 | Shift + 0 |
| GAME | Input Game | SHIFT + TAPE 5 | Shift + 5 |
| AUX | Input AUX | SHIFT + AUX - HDD 7 | Shift + 7 |
| TUNER | Input Tuner | SHIFT + TUNER 6 | Shift + 6 |
| TV/CD | Input TV/CD | SHIFT + CD - STB 3 | Shift + 3 |
| TV/CD | Input TV/CD | SHIFT + TV 1 | Shift + 1 |
| PORT | Input Port | SHIFT + USB 8 | Shift + 8 |
| TONE | Tone | GOTO TEXT | Text / Goto |
| TUN MODE | Tun Mode | LIST SMART | Smart / List |
| MUTING | Muting | DIMMER MUTE | Mute / Dimmer |
| + | Tone + | SHIFT + TUNE+ | Shift + >> / |
| CH + | CH + Port | CH PAGE + | CH+ / Page+ |

| Original | | Sustituto | |
|---|---|---|---|
| VOL | Vol + | VOL + | Vol + |
| − | Tone - | SHIFT + TUNE- | Shift + << / |
| CH − | CH - Port | CH PAGE − | CH- / Page- |
| VOL − | Vol - | VOL − | Vol - |
| | Up Port | | Up |
| PLAYLIST /CATEGORY | Left / Playlist/Category | | Left |
| ENTER | Enter Port | OK | OK |
| PLAYLIST /CATEGORY | Right / Playlist/Category | | Right |
| SETUP | Setup Port | OPT-TOOLS SETUP | Setup / OPT / |
| | Down Port | | Down |
| RETURN | Return Port | RETURN BACK | Back / Return |
| | I<< Port | PRESET- | I<< / Preset- |
| | >>I Port | PRESET+ | >>I / Preset+ |
| | << Port | TUNE- | << / Tune- |
| | Play Port | SLOW | Play / Slow |
| | >> Port | TUNE+ | >> / Tune+ |
| | Pause / Play Reverse Port | STEP - FREEZE | Pause / Step / Freeze |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Stop Port | HOLD Stop / Hold | +10 / Dimmer | GUIDE EPG Guide / EPG / -/-- |
| MOVIE/TV SEARCH Movie/TV / Search Port | NETFLIX SEARCH Red / Netflix / Search | +10 / Dimmer | SHIFT + DIMMER MUTE Shift + Mute / Dimmer |
| MOVIE/TV SEARCH Movie/TV / Search Port | SHIFT + NETFLIX SEARCH Shift + Red / Netflix / | 0 Port | HDMI - SAT 0 0 |
| MUSIC REPEAT Music / Repeat | APP REPEAT Green / APP / Repeat | CLR SLEEP CLR / Sleep Port | CLEAR EXIT CANCEL Exit / Cancel / Clear |
| MUSIC REPEAT Music / Repeat | SHIFT + APP REPEAT Shift + Green / APP / | CLR SLEEP CLR / Sleep Port | TIMER SLEEP Sleep / Timer |
| GAME RANDOM Game / Random | SHIFT + Prime Video RANDOM Shift + Blue / Prime | | |
| GAME RANDOM Game / Random | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| STEREO PLAY MODE Stereo / Play Mode Port | Prime Video RANDOM Blue / Prime Video / Random | | |
| 1 Port | TV 1 1 | | |
| 2 Port | DVD 2 2 | | |
| 3 Port | CD - STB 3 3 | | |
| 4 Port | VIDEO 4 4 | | |
| 5 Port | TAPE 5 5 | | |
| 6 Port | TUNER 6 6 | | |
| 7 Port | AUX - HDD 7 7 | | |
| 8 Port | USB 8 8 | | |
| 9 Port | BLUETOOTH 9 9 | | |