Original		Sustituto	
ON/STANDBY	Power		Power
DISPLAY	Display	DISPLAY INFO	Info
DVD/BD	DVD / BD	SHIFT + 1	Shift + 1
VCR/DVR	VCR / DVR	SHIFT + 2	Shift + 2
CBL/SAT	CBL/SAT	SHIFT + 3	Shift + 3
CD	CD	SHIFT + 4	Shift + 4
AUX	AUX	SHIFT + 5	Shift + 5
TV/TAPE	TV / TAPE	SHIFT + 6	Shift + 6
TUNER	TUNER	SHIFT + 7	Shift + 7
PORT	PORT	SHIFT + 8	Shift + 8
MUTING	Muting	MUTE	Mute
CH DISC	CH/Disc/Album	+ CH	Ch +
ALBUM	CH/Disc/Album	CH −	Ch -
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL −	Vol -
	Up		Up
PLAYLIST /CATEGORY	Left		Left

Original		Sustituto	
ENTER	Enter	OK	Ok
PLAYLIST /CATEGORY	Right		Right
	Down		Down
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
AUDIO	Audio	SOUND DUAL	Dual
	I<<		I<<
	>>I		>>I
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
	Pause		Pause
	Stop		Stop
MOVIE/TV SEARCH	Movie	A	Red
LISTEN MUSIC REPEAT	Music/Repeat	B	Green
G MODE GAME RANDOM	Game/Random	C	Yellow
STEREO PLAY MODE	Stereo/Play Mode	D	Blue

Original		Sustituto		Original	Sustituto
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0 / 11	0/ 11	0	0		
+10/ - - / - - - 10/ Di m er / D. Tun	+10/ - - / - - - 10/ Di m er / D. Tun	GUIDE	Gui de		
CLR/ Sl eep/ 12	CLR/ Sl eep/ 12	PRE-CH	Pr e Ch		

Original		Sustituto	
ON/STANDBY	Power BD/DVD		Power
PREV CH/MENU	Menu/Prev CH	TOP MENU MENU	Menu
GUIDE/TOP MENU	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
SETUP	Setup BD/DVD	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO	Audio BD/DVD	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
PLAYLIST /CATEGORY	Right BD/DVD		Right
PLAYLIST /CATEGORY	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
	Play BD/DVD	PLAY MODE	Play
	Pause/Play rev. BD/DVD		Pause

Original		Sustituto	
	Stop BD/DVD		Stop
MOVIE/TV SEARCH	Movie Tv/Search BD/DVD	A	Red
LISTENI MUSIC REPEAT	Music/Repeat	B	Green
G MODE GAME RANDOM	Game/Random	C	Yellow
STEREO PLAY MODE	Stereo/Play Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer BD/DVD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Original	Sustituto
CBL/SAT	REPEAT TEXT — Text
Muting Receiver	MUTE — Mute
Vol + Receiver	+ VOL — Vol +
Vol - Receiver	VOL − — Vol -
Power CBL/SAT	SHIFT + Power — Shift + Power
CH Disc/Album+ CBL/SAT	+ CH — Ch +
CH Disc/Album- CBL/SAT	CH − — Ch -
Menu/Prev CH CBL/SAT	SHIFT + TOP MENU MENU — Shift + Menu
Top Menu/Guide CBL/SAT	SHIFT + SETTINGS OPT — Shift + Options
Return CBL/SAT	SHIFT + RETURN BACK — Shift + Back
Setup CBL/SAT	SHIFT + HOME SMART — Shift + Smart
Up CBL/SAT	SHIFT + ▲ — Shift + Up
Enter CBL/SAT	SHIFT + OK — Shift + Ok
Down CBL/SAT	SHIFT + ▼ — Shift + Down
Right CBL/SAT	SHIFT + ▶ — Shift + Right
Left CBL/SAT	SHIFT + ◀ — Shift + Left
Pause/Play rev. CBL/SAT	SHIFT + ❚❚ — Shift + Pause

Original	Sustituto
Stop CBL/SAT	SHIFT + ■ — Shift + Stop
<< CBL/SAT	SHIFT + CH − — Shift + Ch -
>> CBL/SAT	SHIFT + + CH — Shift + Ch +
Play CBL/SAT	ECO 3D — 3D
Movie Tv/Search CBL/SAT	SOUND DUAL — Dual
Music/Repeat CBL/SAT	AD SUBT — Subt
Game/Random	TIMER AV — AV
Stereo/Play Mode CBL/SAT	PICTURE FORMAT — Format
1 CBL/SAT	SHIFT + 1 — Shift + 1
2 CBL/SAT	SHIFT + 2 — Shift + 2
3 CBL/SAT	SHIFT + 3 — Shift + 3
4 CBL/SAT	SHIFT + 4 — Shift + 4
5 CBL/SAT	SHIFT + 5 — Shift + 5
6 CBL/SAT	SHIFT + 6 — Shift + 6
7 CBL/SAT	SHIFT + 7 — Shift + 7
8 CBL/SAT	SHIFT + 8 — Shift + 8
9 CBL/SAT	SHIFT + 9 — Shift + 9

Original		Sustituto		Original	Sustituto
0/ 11	CBL/ SAT	SHIFT + 0	Shift + 0		
DVD/BD	DVD/ BD	SEARCH TV/R	TV/ R		

Original		Sustituto	
ON/STANDBY	Power CD		Power
CH DISC	CH/Disc+ CD	CH +	Ch +
ALBUM	CH/Disc- CD	CH −	Ch -
RETURN	Return CD	RETURN BACK	Back
SETUP	Setup CD	HOME SMART	Smart
AUDIO	Audio CD	APP MEDIA	Media
	Up CD		Up
	Down CD		Down
PLAYLIST /CATEGORY	Right CD		Right
PLAYLIST /CATEGORY	Left CD		Left
ENTER	Enter CD	OK	Ok
	I<< CD		I<<
	>>I CD		>>I
	<< CD		<<
	>> CD		>>
	Play CD	PLAY MODE	Play
	Pause CD		Pause

Original		Sustituto	
	Stop CD		Stop
MOVIE/TV SEARCH	Movie Tv/Search	A	Red
LISTENI MUSIC REPEAT	Music/Repeat	B	Green
G MODE GAME RANDOM	Game/Random	C	Yellow
STEREO PLAY MODE	Stereo/Play Mode	D	Blue
1	1 CD	1	1
2	2 CD	2	2
3	3 CD	3	3
4	4 CD	4	4
5	5 CD	5	5
6	6 CD	6	6
7	7 CD	7	7
8	8 CD	8	8
9	9 CD	9	9
11 0	0/11 CD	0	0
10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer CD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

CD

Original	Sustituto	Original	Sustituto
MUTING Muting Receiver	MUTE Mute		
VOL + Vol + Receiver	+ VOL Vol +		
VOL - Vol - Receiver	VOL – Vol -		
CD CD	SEARCH TV/R TV/R		

Original		Sustituto	
ON/STANDBY	Power Receiver Zone 2		Power
MUTING	Muting Receiver	MUTE	Mute
VOL	Vol + Zone 2	+ VOL	Vol +
VOL	Vol - Zone 2	VOL −	Vol -
CH DISC	CH Disc/Album+ Zone 2	+ CH	Ch +
ALBUM	CH Disc/Album- Zone 2	CH −	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
PLAYLIST /CATEGORY	Right Zone 2		Right
PLAYLIST /CATEGORY	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
SETUP	Setup Zone 2	HOME SMART	Smart
AUDIO	Audio Zone 2	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
	Play Zone 2	PLAY MODE	Play

Original		Sustituto	
	>> Zone 2		>>
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
MOVIE/TV SEARCH	Movie Tv/Search Zone 2	A	Red
LISTENING MUSIC REPEAT	Music/Repeat	B	Green
G MODE GAME RANDOM	Game/Random	C	Yellow
STEREO PLAY MODE	Stereo/Play Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9

Original		Sustituto	
11 0	0/11 Zone 2	0	0
10 +10 D.TUN DIMMER	+10/--/--10/D.Tuner Dimmer Zone 2	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

Original	Sustituto