Original		Sustituto	
	Power On		Power
	Power/Standby	SHIFT +	Shift + Power
	Sleep	PROG SLEEP	Sleep
	Display/DVD	APP MEDIA	Media
	OSD Menu	TOP MENU MENU	Menu
	CH+	+ CH	Ch +
	CH-	CH −	Ch -
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Up		Up
	Left		Left
	Enter	OK	Ok
	Right		Right
	Down		Down
	Exit/Return	CLEAR EXIT	Exit
	Test/Tv/VCR	SEARCH TV/R	TV/R
	Muting	MUTE	Mute

Original		Sustituto	
	I<<		I<<
	Play	PLAY MODE	Play
	>>I		>>I
	<<		<<
	Stop		Stop
	>>		>>
REC	Rec	REC MODE	Rec
	Pause		Pause
OPEN/CLOSE	Eject	ZOOM	Eject
DVD	DVD	SETTINGS OPT	Options
CD	CD	REPEAT TEXT	Text
T1	T1	PICTURE FORMAT	Format
T2	T2	SOUND DUAL	Dual
TUN	Tun	TIMER AV	AV
PH	PH	ECO 3D	3D
V1	V1	A	Red
V2	V2	B	Green

Original		Sustituto		Original		Sustituto	
V3	V3	C	Yellow				
V_	V4	D	Blue				
STEREO 1	1/Stereo	1	1				
DIRECT 2	2/Direct	2	2				
DSP 3	3/DSP>	3	3				
SURROUND 4	4/Surround	4	4				
THX 5	5/THX	5	5				
DSP 6	6/DSP<	6	6				
Re-EQ 7	7/Re-EQ	7	7				
CH SEL 8	8/CH Sel	8	8				
LEVEL+ 9	9/Level +	9	9				
LATE NIGHT +10	+10/Late Night	-/-- GUIDE	Guide				
DIMMER 0	0/Dimmer	0	0				
LEVEL- ENT	ENT/Level -	FAV PRE-CH	Pre Ch				

Original		Sustituto	
ON	Power		Power
DISPLAY DVD SET	Display DVD	APP MEDIA	Media
OSD MENU	OSD Menu	TOP MENU MENU	Menu
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
EXIT RETURN	Exit/Return	CLEAR EXIT	Exit
	I<<		I<<
	Play	PLAY MODE	Play
	>>I		>>I
	<<		<<
	Stop		Stop
	>>		>>
	Pause		Pause
OPEN/CLOSE	Eject	ZOOM	Eject

Original		Sustituto	
STEREO 1	1	1	1
DIRECT 2	2	2	2
DSP 3	3	3	3
SURROUND 4	4	4	4
THX 5	5	5	5
DSP 6	6	6	6
Re-EQ 7	7	7	7
CH SEL 8	8	8	8
LEVEL+ 9	9	9	9
DIMMER 0	0	0	0
LATE NIGHT +10	+10	-/-- GUIDE	Guide
LEVEL- ENT	Ent	FAV PRE-CH	Pre Ch

Original		Sustituto	
	Play	PLAY MODE	Play
	Stop		Stop
	Pause		Pause
	I <<		I <<
	<<		<<
	>>		>>
TRACK	Track	HOME SMART	Smart
DISC	Disc	APP MEDIA	Media
	>>I		>>I
OPEN/CLOSE	Eject	ZOOM	Eject
STEREO 1	1	1	1
DIRECT 2	2	2	2
DSP 3	3	3	3
SURROUND 4	4	4	4
THX 5	5	5	5
DSP 6	6	6	6
Re-EQ 7	7	7	7

Original		Sustituto	
CH SEL 8	8	8	8
LEVEL+ 9	9	9	9
LATE NIGHT +10	+10	-/-- GUIDE	Guide
DIMMER 0	0	0	0

Original		Sustituto	
ON	Power		Power
	I <<		I <<
	Play	PLAY MODE	Play
	>>I		>>I
	<<		<<
	Stop		Stop
	>>		>>
REC	Rec	REC MODE	Rec
	Pause		Pause
OPEN/CLOSE	Eject	ZOOM	Eject
STEREO 1	1	1	1
DIRECT 2	2	2	2
DSP 3	3	3	3
SURROUND 4	4	4	4
THX 5	5	5	5
DSP 6	6	6	6
Re-EQ 7	7	7	7

Original		Sustituto	
CH SEL 8	8	8	8
LEVEL+ 9	9	9	9
LATE NIGHT +10	+10	-/-- GUIDE	Guide
LEVEL- ENT	Ent	FAV PRE-CH	Pre Ch