Original		Sustituto	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	(O	LANG I/II AUDIO	Audio / Lang I/II
	[<>]	FORMAT PICTURE	Picture / Format
	Green/Timer	TIMER SLEEP	Sleep / Timer
	>I <	TOP MENU D.MENU	D.Menu / Top
	[1I 2]	OPT-TOOLS SETUP	Setup / OPT /
	[≡]	GOTO TEXT	Text / Goto
	Source	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	[i +]	ANGLE INFO	Info / Angle

Original		Sustituto	
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Vol +	+ VOL	Vol +
Active Control	[-O-] / Active Control	LIST SMART	Smart / List
P	P+	+ CH PAGE	CH+ / Page+
	Vol -	VOL -	Vol -
P	P-	CH PAGE -	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8

Original	Sustituto	Original	Sustituto
9	9	Right AMP	Shift + Right
Guide	Guide / EPG / -/--	Down AMP	Shift + Down
0	0	Vol + AMP	Shift + Vol +
P<P	Fav / Marker / PC	P+ AMP	Shift + CH+ /
Red	Red / Netflix / Search	Vol - AMP	Shift + Vol -
Green/Timer	Green / APP / Repeat	P- AMP	Shift + CH- /
Yellow/[ ]	Yellow / YouTube / Repeat	1 AMP	Shift + 1
Blue/[...]	Blue / Prime Video / Random	2 AMP	Shift + 2
Power AMP	Shift + Power	3 AMP	Shift + 3
Mute AMP	Shift + Mute / Dimmer	4 AMP	Shift + 4
<< AMP	Shift + << /	5 AMP	Shift + 5
>> AMP	Shift + >> /	6 AMP	Shift + 6
[≡] AMP	Shift + Text /	7 AMP	Shift + 7
Menu AMP	Shift + Menu /	8 AMP	Shift + 8
Up AMP	Shift + Up	9 AMP	Shift + 9
Left AMP	Shift + Left	Guide AMP	Shift + Guide / EPG / -/--
OK AMP	Shift + OK	0 AMP	Shift + 0

Original	Sustituto	Original	Sustituto
P<P AMP	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC		

Original	Sustituto	Original	Sustituto
Power	Power	P+	CH+ / Page+
Source	AV / Input / RDS	Vol -	Vol -
>>	>> / Tune+	P-	CH- / Page-
<<	<< / Tune-	1	1
Stop	Stop / Hold	2	2
Play	Play / Slow	3	3
Guide	Guide / EPG / -/--	4	4
[≡]	Text / Goto	5	5
Up	Up	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
Down	Down	[i+]	Info / Angle
>I<	D.Menu / Top	0	0
Menu	Menu / Home	P<P	Fav / Marker / PC
Vol +	Vol +	[1l2]	Setup / OPT /
Mute	Mute / Dimmer	[-O-]/Active Control	Smart / List

Original	Sustituto	Original	Sustituto
[<>]	FORMAT PICTURE Picture / Format		

Original	Sustituto	Original	Sustituto
Power	Power	OK	OK
Mute	Mute / Dimmer	Right	Right
Play	Play / Slow	Down	Down
Stop	Stop / Hold	Vol +	Vol +
Rec	Rec / Rec Mode	[-O-] / Active Control	Smart / List
<<	<< / Tune-	P+	CH+ / Page+
>>	>> / Tune+	Vol -	Vol -
(O	Audio / Lang I/II	P-	CH- / Page-
[<>]	Picture / Format	1	1
Green/Timer	Sleep / Timer	2	2
>I<	D.Menu / Top	3	3
[1I2]	Setup / OPT /	4	4
Source	AV / Input / RDS	5	5
Menu	Menu / Home	6	6
Up	Up	7	7
[i+]	Info / Angle	8	8
Left	Left	9	9

Original	Sustituto
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green/Timer	Green / APP / Repeat
Yellow/[ ]	Yellow / YouTube / Repeat
Blue/[...]	Blue / Prime Video / Random
Power VCR	Shift + Power
Play VCR	Shift + Play /
Stop VCR	Shift + Stop /
Rec VCR	Shift + Rec / Rec Mode
<< VCR	Shift + << /
>> VCR	Shift + >> /
>I < VCR	Shift + D. Menu / Top Menu
Source VCR	Shift + AV / Input / RDS
Menu VCR	Shift + Menu /
Up VCR	Shift + Up
[i+] VCR	Shift + Info / Angle

Original	Sustituto
Left VCR	Shift + Left
OK VCR	Shift + OK
Right VCR	Shift + Right
Down VCR	Shift + Down
P+ VCR	Shift + CH+ /
P- VCR	Shift + CH- /
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9
0 VCR	Shift + 0
P<P VCR	Shift + Fav / Marker / PC

Original		Sustituto	
	Power		Power
	>>		>> / Tune+
	<<		<< / Tune-
	Stop		Stop / Hold
	Play		Play / Slow
	Guide		Guide / EPG / -/--
	Up		Up
	Left		Left
	Right		Right
	Down		Down
	>I<		D.Menu / Top
	Vol +		Vol +
	Mute		Mute / Dimmer
	P+		CH+ / Page+
	Vol -		Vol -
	P-		CH- / Page-
	1		1

Original		Sustituto	
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	[i+]		Info / Angle
	0		0
	P<P		Fav / Marker / PC