Mandis shop

Panasonic VEQ1110

Original		Sustituto	
VTR	VTR	Power	
CLOCK/ COUNTER	Clock/Counter	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
RESET	Reset	CLEAR / EXIT / CANCEL	Exit / Cancel / Clear
MEMORY/ REPEAT/SEARCH	Memory/Repeat/Search	APP / REPEAT	Green / APP / Repeat
REV.PLAY	Rev.Play	SURROUND	Eject / Surround
REC	Rec	REC MODE	Rec / Rec Mode
PAUSE/STILL	Pause/Still	STEP - FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
STILL ADV	Still Adv	PRESET+	>>I / Preset+
REW/	<<	TUNE-	<< / Tune-
PLAY/x2	Play	SLOW	Play / Slow
/FF	>>	TUNE+	>> / Tune+
–	Slow-		Left
SLOW	Slow	OK	OK
SLOW	Slow	SHIFT + SLOW	Shift + Play /
+	Slow+		Right
1	1	TV 1	1

Original		Sustituto	
2	2	DVD 2	2
3	3	CD - STB 3	3
TIME SEA	Time Search	Prime Video / RANDOM	Blue / Prime Video / Random
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
MONITOR	Monitor	MEDIA DISPLAY	Display / Media
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
AV 0	0/AV	HDMI - SAT 0	0
AV 0	0/AV	RDS AV INPUT	AV / Input / RDS
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--

https://mandos-a-distancia.es/es/Panasonic/1066781-51280-mando-de-sustitucion-para-Panasonic-VEQ1110.html