Mandis shop

Philips 996580004176

Original		Sustituto	
	Power		Power
COAX	Coax	HOME SMART	Smart
OPT	OPT	SETTINGS OPT	Options
AUDIO IN	Audio In	SOUND DUAL	Dual
	Blutooth		Up
USB	USB		Down
AUX	AUX	APP MEDIA	Media
	Play	PLAY MODE	Play
	Pause		Pause
	Play/Pause	OK	Ok
	>I		>>I
	>I		Right
	I<		I<<
	I<		Left
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
	Mute	MUTE	Mute

Original		Sustituto	
AUDIO SYNC +	Audio Sync+	CH +	Ch +
AUDIO SYNC −	Audio Sync-	CH −	Ch -
BASS +	Bass+	1	1
BASS −	Bass-	4	4
SURR	Surr	2	2
NIGHT	Night	5	5
TREBLE +	Treble+	3	3
TREBLE −	Treble-	6	6

https://mandos-a-distancia.es/es/Philips/1056002-65454-mando-de-sustitucion-para-Philips-996580004176.html