Mandis shop

Philips 996580008742

Original		Sustituto	
	Power		Power
	Play	PLAY MODE	Play
	Pause		Pause
	I<		I<<
	>I		>>I
COAX	Coax	A	Red
OPTICAL	Optical	B	Green
AUX	AUX	C	Yellow
AUDIO IN	Audio In	D	Blue
	Bluetooth	HOME SMART	Smart
USB	USB	APP MEDIA	Media
HDMI ARC	HDMI ARC	SETTINGS OPT	Options
+	Vol+	+ VOL	Vol +
–	Vol-	VOL –	Vol -
	Mute	MUTE	Mute
+ TREBLE	Treble+	+ CH	Ch +
TREBLE –	Treble-	CH –	Ch -

Original		Sustituto	
+ BASS	Bass+		Up
BASS –	Bass-		Down
MUSIC	Music	SEARCH TV/R	TV/R
SURR	Surr	SOUND DUAL	Dual
NIGHT	Night	FAV PRE-CH	Pre Ch
DIM	DIM	- / -- GUIDE	Guide
+	Audio Sync+		Right
–	Audio Sync-		Left
VOICE	Voice	DISPLAY INFO	Info

https://mandos-a-distancia.es/es/Philips/1056200-66031-mando-de-sustitucion-para-Philips-996580008742.html