| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Power | Power | Left | Left |
| Mute | Mute / Dimmer | OK | OK |
| Play | Play / Slow | Right | Right |
| Stop | Stop / Hold | Down | Down |
| Rec | Rec / Rec Mode | Vol + | Vol + |
| << | << / Tune- | [-O-]/Active Control | Smart / List |
| >> | >> / Tune+ | P+ | CH+ / Page+ |
| (O | Audio / Lang I/II | Vol - | Vol - |
| [<>] | Picture / Format | P- | CH- / Page- |
| Green/Timer | Sleep / Timer | 1 | 1 |
| >I< | D.Menu / Top | 2 | 2 |
| [1I2] | Setup / OPT / | 3 | 3 |
| [≡] | Text / Goto | 4 | 4 |
| Source | AV / Input / RDS | 5 | 5 |
| Menu | Menu / Home | 6 | 6 |
| Up | Up | 7 | 7 |
| [i+] | Info / Angle | 8 | 8 |

| Original | Sustituto |
|---|---|
| 9 | 9 |
| Guide | Guide / EPG / -/-- |
| 0 | 0 |
| P<P | Fav / Marker / PC |
| Red | Red / Netflix / Search |
| Green/Timer | Green / APP / Repeat |
| Yellow/[ ] | Yellow / YouTube / Repeat |
| Blue/[...] | Blue / Prime Video / Random |
| Power AMP | Shift + Power |
| Mute AMP | Shift + Mute / Dimmer |
| << AMP | Shift + << / |
| >> AMP | Shift + >> / |
| [≡] AMP | Shift + Text / |
| Menu AMP | Shift + Menu / |
| Up AMP | Shift + Up |
| Left AMP | Shift + Left |
| OK AMP | Shift + OK |

| Original | Sustituto |
|---|---|
| Right AMP | Shift + Right |
| Down AMP | Shift + Down |
| Vol + AMP | Shift + Vol + |
| P+ AMP | Shift + CH+ / |
| Vol - AMP | Shift + Vol - |
| P- AMP | Shift + CH- / |
| 1 AMP | Shift + 1 |
| 2 AMP | Shift + 2 |
| 3 AMP | Shift + 3 |
| 4 AMP | Shift + 4 |
| 5 AMP | Shift + 5 |
| 6 AMP | Shift + 6 |
| 7 AMP | Shift + 7 |
| 8 AMP | Shift + 8 |
| 9 AMP | Shift + 9 |
| Guide AMP | Shift + Guide / EPG / -/-- |
| 0 AMP | Shift + 0 |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| P<P AMP | SHIFT + PC FAV MARKER Shift + Fav / Marker / PC | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Power | Power | P+ | CH+ / Page+ |
| Source | AV / Input / RDS | Vol - | Vol - |
| >> | >> / Tune+ | P- | CH- / Page- |
| << | << / Tune- | 1 | 1 |
| Stop | Stop / Hold | 2 | 2 |
| Play | Play / Slow | 3 | 3 |
| Guide | Guide / EPG / -/-- | 4 | 4 |
| [≡] | Text / Goto | 5 | 5 |
| Up | Up | 6 | 6 |
| Left | Left | 7 | 7 |
| OK | OK | 8 | 8 |
| Right | Right | 9 | 9 |
| Down | Down | [i+] | Info / Angle |
| >I< | D. Menu / Top | 0 | 0 |
| Menu | Menu / Home | P<P | Fav / Marker / PC |
| Vol + | Vol + | [1I2] | Setup / OPT / |
| Mute | Mute / Dimmer | [-O-]/Active Control | Smart / List |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| [ <>] | FORMAT PICTURE Picture / Format | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Sustituto | |
|---|---|---|---|
| | Power | | Power |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Play | SLOW | Play / Slow |
| | Stop | HOLD | Stop / Hold |
| | Rec | REC MODE | Rec / Rec Mode |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| | (O | LANG I/II AUDIO | Audio / Lang I/II |
| | [<>] | FORMAT PICTURE | Picture / Format |
| | Green/Timer | TIMER SLEEP | Sleep / Timer |
| | >I< | TOP MENU D.MENU | D.Menu / Top |
| | [1I2] | OPT-TOOLS SETUP | Setup / OPT / |
| | Source | RDS AV INPUT | AV / Input / RDS |
| | Menu | HOME MENU | Menu / Home |
| | Up | | Up |
| | [i+] | ANGLE INFO | Info / Angle |
| | Left | | Left |

| Original | | Sustituto | |
|---|---|---|---|
| | OK | | OK |
| | Right | | Right |
| | Down | | Down |
| | Vol + | VOL + | Vol + |
| | [-O-]/Active Control | LIST SMART | Smart / List |
| | P+ | CH PAGE + | CH+ / Page+ |
| | Vol - | VOL − | Vol - |
| | P- | CH PAGE − | CH- / Page- |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |

| Original | Sustituto |
|---|---|
| 0 | 0 |
| P<P | Fav / Marker / PC |
| Red | Red / Netflix / Search |
| Green/Timer | Green / APP / Repeat |
| Yellow/[ ] | Yellow / YouTube / Repeat |
| Blue/[...] | Blue / Prime Video / Random |
| Power VCR | Shift + Power |
| Play VCR | Shift + Play / |
| Stop VCR | Shift + Stop / |
| Rec VCR | Shift + Rec / Rec Mode |
| << VCR | Shift + << / |
| >> VCR | Shift + >> / |
| >I < VCR | Shift + D. Menu / Top Menu |
| Source VCR | Shift + AV / Input / RDS |
| Menu VCR | Shift + Menu / |
| Up VCR | Shift + Up |
| [i+] VCR | Shift + Info / Angle |

| Original | Sustituto |
|---|---|
| Left VCR | Shift + Left |
| OK VCR | Shift + OK |
| Right VCR | Shift + Right |
| Down VCR | Shift + Down |
| P+ VCR | Shift + CH+ / |
| P- VCR | Shift + CH- / |
| 1 VCR | Shift + 1 |
| 2 VCR | Shift + 2 |
| 3 VCR | Shift + 3 |
| 4 VCR | Shift + 4 |
| 5 VCR | Shift + 5 |
| 6 VCR | Shift + 6 |
| 7 VCR | Shift + 7 |
| 8 VCR | Shift + 8 |
| 9 VCR | Shift + 9 |
| 0 VCR | Shift + 0 |
| P<P VCR | Shift + Fav / Marker / PC |

| Original | Sustituto |
|---|---|
| Power | Power |
| >> | >> / Tune+ |
| << | << / Tune- |
| Stop | Stop / Hold |
| Play | Play / Slow |
| Guide | Guide / EPG / -/-- |
| Up | Up |
| Left | Left |
| Right | Right |
| Down | Down |
| >I < | D. Menu / Top |
| Vol + | Vol + |
| Mute | Mute / Dimmer |
| P+ | CH+ / Page+ |
| Vol - | Vol - |
| P- | CH- / Page- |
| 1 | 1 |

| Original | Sustituto |
|---|---|
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| [i +] | Info / Angle |
| 0 | 0 |
| P<P | Fav / Marker / PC |