Original		Sustituto	
	Swap	LIST SMART	Smart / List
	Text	GOTO TEXT	Text / Goto
	Media	MEDIA DISPLAY	Display / Media
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
	Back	RETURN BACK	Back / Return
	FAV	PC FAV MARKER	Fav / Marker / PC

Original		Sustituto	
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	i	ANGLE INFO	Info / Angle
	V-Format	FORMAT PICTURE	Picture / Format
	Vol +	+ VOL	Vol +
	Page+	SHIFT + CH PAGE +	Shift + CH+ /
	P+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
	Page-	SHIFT + CH PAGE −	Shift + CH- /
	P-	CH PAGE −	CH- / Page-
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	AD	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
	Sound / TV/Radio	TITLE SOUND	Sound / Title
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right

Original	Sustituto	Original	Sustituto
Menu	Menu / Home		
Down	Down		
Exit	Exit / Cancel / Clear		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		
Rec	Rec / Rec Mode		
<<	<< / Tune-		
>>	>> / Tune+		
I <<	I << / Preset-		
>>I	>>I / Preset+		
Timer	Sleep / Timer		
Aspect	Zoom / Size		