Original		Sustituto	
	Power		Power
FILE MODE	File Mode	TOP MENU D.MENU	D. Menu / Top
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
SUSPEND	Suspend	RDS AV INPUT	AV / Input / RDS
PAGE UP	Page Up	CH PAGE +	CH+ / Page+
USB	USB	SHIFT + USB 8	Shift + 8
TV MODE	TV Mode	PROGRAM TV/RADIO	TV/Radio /
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PAGE DOWN	Page Down	CH PAGE −	CH- / Page-
1 .:/@	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD-STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX-HDD 7	7
8 tuv	8	USB 8	8

Original		Sustituto	
9 wxyz	9	BLUETOOTH 9	9
DELETE	Delete	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
CAPS/NUM	CAPS/NUM	PC FAV MARKER	Fav / Marker / PC
RETURN	Return	RETURN BACK	Back / Return
SOURCE	Source	SURROUND	Eject / Surround
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
INFO	Info	ANGLE INFO	Info / Angle
	Down		Down
HOME	Home	SHIFT + HOME MENU	Shift + Menu /
MENU	Menu	HOME MENU	Menu / Home
PREV	I<<	PRESET-	I<< / Preset-
PLAY	Play	SLOW	Play / Slow
NEXT	>>I	PRESET+	>>I / Preset+

Original		Sustituto		Original	Sustituto
TITLE	Title	TITLE SOUND	Sound / Title		
REV	<<	TUNE-	<< / Tune-		
STOP	Stop	HOLD	Stop / Hold		
FWD	>>	TUNE+	>> / Tune+		
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /		
ANGLE	Angle	SHIFT + ANGLE INFO	Shift + Info / Angle		
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze		
SLOW	I>	SHIFT + SLOW	Shift + Play /		
TIME SEEK	Time Seek	TIMER SLEEP	Sleep / Timer		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
ZOOM	Zoom	SIZE ZOOM	Zoom / Size		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		