Original		Sustituto	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
DISPLAY	Display	MEDIA DISPLAY	Display / Media
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
PHOTO	Photo	TIMER SLEEP	Sleep / Timer
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
MUSIC	Music	TITLE SOUND	Sound / Title
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
MOVIE	Movie	SIZE ZOOM	Zoom / Size
0	0	HDMI-SAT 0	0

Original		Sustituto	
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
FILE	File	RETURN BACK	Back / Return
MUSIC SLIDESHOW	Music SL Ideshow	LANG I/II AUDIO	Audio / Lang I/II
	Up		Up
VGA	VGA	PROGRAM TV/RADIO	TV/Radio /
+	Vol +	+ VOL	Vol +
	Left		Left
	Enter	OK	OK
	Play	SLOW	Play / Slow
	Right		Right
PHOTO ROTATION	Photo Rotation	PC FAV MARKER	Fav / Marker / PC
	Down		Down
PHOTO ZOOM	Photo Zoom	LIST SMART	Smart / List
–	Vol -	VOL –	Vol -
PHOTO TRANSITION	Photo Transition	FORMAT PICTURE	Picture / Format
PHOTO DURATION	Photo Duration	SURROUND	Eject / Surround

Original	Sustituto	Original	Sustituto
PAUSE Pause	STEP-FREEZE Pause / Step / Freeze		
STOP Stop	HOLD Stop / Hold		
REV <<	TUNE- << / Tune-		
FWD >>	TUNE+ >> / Tune+		
PREV I <<	PRESET- I << / Preset-		
NEXT >>I	PRESET+ >>I / Preset+		