Mandis shop

Sony RMSR5

| Original | Sustituto |
|---|---|
| Disc Skip | Blue / Prime Video / Random |
| Sleep | Sleep / Timer |
| Power | Power |
| CD Play | Play / Slow |
| Pause | Pause / Step / Freeze |
| Stop | Stop / Hold |
| Tuner/Band | Yellow / YouTube / Repeat |
| I<< | I<< / Preset- |
| >>I | >>I / Preset+ |
| Deck A Play | Red / Netflix / Search |
| << | << / Tune- |
| >> | >> / Tune+ |
| Deck B Play | Green / APP / Repeat |
| Check | Display / Media |
| Clear | Exit / Cancel / Clear |
| MD Play | Shift + Play / |
| Pause MD | Shift + Pause / Step / Freeze |

| Original | Sustituto |
|---|---|
| Stop MD | Shift + Stop / |
| Loop | Smart / List |
| Flash | Info / Angle |
| Function | Menu / Home |
| Up | Up |
| Vol + | Vol+ |
| On /Off | OK |
| Down | Down |
| Vol - | Vol- |

https://mandos-a-distancia.es/es/Sony/1058651-23109-mando-de-sustitucion-para-Sony-RM-SR5-147557211.html