Original		Sustituto	
CONTINUE	Continue Play	GOTO TEXT	Text / Goto
SHUFFLE	Shuffle Play Mod	RDS AV INPUT	AV / Input / RDS
PROGRAM	Program Play	OPT-TOOLS SETUP	Setup / OPT /
MUSIC SCAN	Music Scan	LANG I/II AUDIO	Audio / Lang I/II
DISC SKIP	Disc Skip	PC FAV MARKER	Fav / Marker / PC
DISC 1	Disc 1	NETFLIX SEARCH	Red / Netflix / Search
DISC 2	Disc2	APP REPEAT	Green / APP / Repeat
DISC 3	Disc3	YouTube REPEAT A-B	Yellow / YouTube / Repeat
DISC 4	Disc4	Prime Video RANDOM	Blue / Prime Video / Random
DISC 5	Disc5	LIST SMART	Smart / List
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7

Original		Sustituto	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
10	10	HDMI-SAT 0	0
11	11	SHIFT + TV 1	Shift + 1
12	12	SHIFT + DVD 2	Shift + 2
13	13	SHIFT + CD-STB 3	Shift + 3
14	14	SHIFT + VIDEO 4	Shift + 4
15	15	SHIFT + TAPE 5	Shift + 5
16	16	SHIFT + TUNER 6	Shift + 6
17	17	SHIFT + AUX-HDD 7	Shift + 7
18	18	SHIFT + USB 8	Shift + 8
19	19	SHIFT + BLUETOOTH 9	Shift + 9
20	20	SHIFT + HDMI-SAT 0	Shift + 0
>20	>20	-/-- GUIDE EPG	Guide / EPG / -/--
CHECK	Check	MEDIA DISPLAY	Display / Media
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
FILE	File	PROGRAM TV/RADIO	TV/Radio / Program

Original	Sustituto
MEMO INPUT — Memo Input	ANGLE INFO — Info / Angle
TIME — Time	TIMER SLEEP — Sleep / Timer
REPEAT — Repeat	SHIFT + APP REPEAT — Shift + Green / APP /
ERASE — Erase	RETURN BACK — Back / Return
LEVEL FILE — Level File	EQ SUBTITLE — Subtitle / EQ
A — Music Clip A	▲ — Up
B — Music Clip B	▼ — Down
C — Music Clip C	▶ — Right
D — Music Clip D	◀ — Left
▶ — Play	SLOW ▶ — Play / Slow
❚❚ — Pause	STEP-FREEZE ❚❚ — Pause / Step / Freeze
■ — Stop	HOLD ■ — Stop / Hold
FADER — Fader	DIMMER MUTE — Mute / Dimmer
⏮ — I<< AMS	PRESET- ⏮ — I<< / Preset-
⏭ — AMS >>I	PRESET+ ⏭ — >>I / Preset+
+ LINE OUT LEVEL — Line Out Level +	+ VOL — Vol +
◀◀ — <<	TUNE- ◀◀ — << / Tune-

Original	Sustituto
▶▶ — >>	TUNE+ ▶▶ — >> / Tune+
LINE OUT LEVEL − — Line Out Level −	VOL − — Vol -