Original		Sustituto	
I/⏻	Power		Power
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
TUNING – SLOW	<<	TUNE-	<< / Tune-
TUNING + SLOW	>>	TUNE+	>> / Tune+
PROG – PRESET –	I<<</Preset-	PRESET-	I<< / Preset-
PROG + PRESET +	>>I/Preset+	PRESET+	>>I / Preset+
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE D.TUNING	Subtitle/D.Tuning	EQ SUBTITLE	Subtitle / EQ
PICTURE NAVI	Picture Navi	FORMAT PICTURE	Picture / Format
S-AIR MODE	S-Air Mode	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TV INPUT	Tv Input	RDS AV INPUT	AV / Input / RDS
SYSTEM MENU ENTER	System Menu/Enter	TOP MENU D.MENU	D.Menu / Top Menu

Original		Sustituto	
TOOLS DISPLAY	Display/Tools	OPT-TOOLS SETUP	Setup / OPT /
ONE-TOUCH PLAY	One-Touch Play	GOTO TEXT	Text / Goto
DVD MENU	Menu/DVD	HOME MENU	Menu / Home
THEATRE	Theatre	PROGRAM TV/RADIO	TV/Radio /
	Up		Up
ANGLE	Angle	ANGLE INFO	Info / Angle
	Left		Left
	OK	OK	OK
	Right		Right
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOLUME	Volume+	VOL	Vol +
DYNAMIC BASS	Dynamic Bass	LIST SMART	Smart / List
FUNCTION	Function+	CH PAGE	CH+ / Page+
	Volume-	VOL	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Sustituto	
	Function-	CH PAGE	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
NIGHT	Night	NETFLIX SEARCH	Red / Netflix / Search
DVD TOP MENU	DVD Top Menu	APP REPEAT	Green / APP / Repeat
DISC SKIP	Disc Skip	Prime Video RANDOM	Blue / Prime Video / Random
TV I/⏻	Power Tv	SHIFT + ⏻	Shift + Power
	Tv Vol -	SHIFT + VOL –	Shift + Vol -
TV VOL +	Tv Vol +	SHIFT + + VOL	Shift + Vol +

Original		Sustituto	
ADVANCE	· –/ I > Step/ Advance	SHIFT + TUNE+ ▶▶	Shift + >> /
REPLAY	← / ◁ Step/ Repla	SHIFT + TUNE- ◀◀	Shift + << /

Original		Sustituto	
I/⏻	Power	⏻	Power
TV VOL +	Tv Vol +	+ VOL	Vol +
TV INPUT	Tv Input	RDS AV INPUT	AV / Input / RDS
–	Tv Vol -	VOL –	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/-- CLEAR	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
SYSTEM MENU ENTER	Enter	PC FAV MARKER	Fav / Marker / PC
DVD MENU	Menu	HOME MENU	Menu / Home

Original		Sustituto	
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
RETURN	Return	RETURN BACK	Back / Return
▼	Down	▼	Down
TOOLS DISPLAY	Tools	OPT-TOOLS SETUP	Setup / OPT /
PROG – PRESET –	Prog-	CH PAGE –	CH- / Page-
PROG + PRESET +	Prog+	CH PAGE +	CH+ / Page+