

Original		Sustituto	
	Power		Power
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	Play / Pause	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
TXT	TXT	GOTO TEXT	Text / Goto
	Up		Up
	PIP	FORMAT PICTURE	Picture / Format
	Left		Left
OK	OK	OK	OK
	Right		Right
	Mute	DIMMER MUTE	Mute / Dimmer
	Down		Down

Original		Sustituto	
INFO	Info	ANGLE INFO	Info / Angle
+	Vol+	+ VOL	Vol+
MENU	Menu	HOME MENU	Menu / Home
+ P	P+	+ CH PAGE	CH+ / Page+
-	Vol-	VOL -	Vol-
BACK	Back	RETURN BACK	Back / Return
P -	P-	CH PAGE -	CH- / Page-
1 .,-	1	TV 1	1
2 ABC	2	DVD 2	2
3 DEF	3	CD - STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
6 MNO	6	TUNER 6	6
7 PQRS	7	AUX - HDD 7	7
8 TUV	8	USB 8	8
9 WXYZ	9	BLUETOOTH 9	9
CANC	Canc.	CLEAR EXIT CANCEL	Exit / Cancel / Clear





Original		Sustituto		Original		Sustituto	
0	0	HDMI - SAT 0	0				
:::	:::	LIST SMART	Smart / List				

