| Original | | Sustituto | |
|---|---|---|---|
| | Power MD | | Power |
| DIRECT TUNING DISC ENTER | Direct Tuning | REPEAT TEXT | Text |
| DIMMER | Dimmer | FAV PRE-CH | Pre Ch |
| TV | TV | SEARCH TV/R | TV/R |
| CD | CD | C | Yellow |
| DVD | DVD | D | Blue |
| TUNER/ BAND | Tuner/Band | B | Green |
| TAPE | Tape | A | Red |
| VCR | VCR | HOME SMART | Smart |
| MD | MD | APP MEDIA | Media |
| VOL + | Vol + | + VOL | Vol + |
| VOL - | Vol - | VOL - | Vol - |
| MUTING | Muting | MUTE | Mute |
| | Stop MD | ■ | Stop |
| | Play MD | PLAY MODE ▶ | Play |
| | <</I<< MD | « | << |
| | >>/>>I MD | » | >> |

| Original | | Sustituto | |
|---|---|---|---|
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| MENU | Menu | E-MANUAL D.MENU | D. Menu |
| DISPLAY | Display | DISPLAY INFO | Info |
| TOP MENU DISC/DECK 1/2 | Top Menu/Disc/Deck | TOP MENU MENU | Menu |
| 1 | 1 MD | 1 | 1 |
| 2 | 2 MD | 2 | 2 |
| 3 | 3 MD | 3 | 3 |
| 4 | 4 MD | 4 | 4 |
| 5 | 5 MD | 5 | 5 |
| 6 | 6 MD | 6 | 6 |
| 7 | 7 MD | 7 | 7 |
| 8 | 8 MD | 8 | 8 |
| 9 | 9 MD | 9 | 9 |

| Original | | Sustituto | |
|---|---|---|---|
| 0 | 0 MD | 0 | 0 |
| ≥10/-/-- | >10/-/-- MD | -/-- GUIDE | Guide |
| TV/AV | Tv/AV | TIMER AV | AV |
| STEREO | Stereo | SOUND DUAL | Dual |
| SURROUND | Surround | SETTINGS OPT | Options |
| SFC | SFC | AD SUBT | Subt |
| TEST | Test | RETURN BACK | Back |
| DELAY | Delay | PICTURE FORMAT | Format |
| LEVEL | Level | ECO 3D | 3D |
| + | + | + CH | Ch + |
| - | - | CH − | Ch - |
| | Power TV | SHIFT + | Shift + Power |
| VOL ^ | Tv Vol Up | SHIFT + + VOL | Shift + Vol + |
| TV v | Tv Vol Down | SHIFT + VOL − | Shift + Vol - |
| 1 | 1 Tv | SHIFT + 1 | Shift + 1 |
| 2 | 2 Tv | SHIFT + 2 | Shift + 2 |
| 3 | 3 Tv | SHIFT + 3 | Shift + 3 |

| Original | | Sustituto | |
|---|---|---|---|
| 4 | 4 Tv | SHIFT + 4 | Shift + 4 |
| 5 | 5 Tv | SHIFT + 5 | Shift + 5 |
| 6 | 6 Tv | SHIFT + 6 | Shift + 6 |
| 7 | 7 Tv | SHIFT + 7 | Shift + 7 |
| 8 | 8 Tv | SHIFT + 8 | Shift + 8 |
| 9 | 9 Tv | SHIFT + 9 | Shift + 9 |
| 0 | 0 Tv | SHIFT + 0 | Shift + 0 |
| ≥10/-/-- | >10/-/-- Tv | SHIFT + -/-- GUIDE | Shift + Guide |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Power DVD | Power | Right | Right |
| TV | TV/R | Left | Left |
| VCR | Smart | Enter | Ok |
| Tuner/Band | Green | Stereo | Dual |
| Tape | Red | Surround | Options |
| MD | Media | SFC | Subt |
| CD | Yellow | Test | Back |
| DVD | Blue | Delay | Format |
| Play DVD | Play | Level | 3D |
| I<</<< DVD | << | + | Ch + |
| Stop DVD | Stop | - | Ch - |
| >>/>>I DVD | >> | 1 DVD | 1 |
| Top Menu/Disc/Deck | Menu | 2 DVD | 2 |
| Display | Info | 3 DVD | 3 |
| Menu | D. Menu | 4 DVD | 4 |
| Up | Up | 5 DVD | 5 |
| Down | Down | 6 DVD | 6 |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| 7 DVD | 7 | | |
| 8 DVD | 8 | | |
| 9 DVD | 9 | | |
| 0 DVD | 0 | | |
| >10/ - / - - DVD | Gui de | | |
| Vol + | Vol + | | |
| Vol - | Vol - | | |
| Mut i ng | Mut e | | |

| Original | | Sustituto | |
|---|---|---|---|
| | Power CD | | Power |
| TV | TV | SEARCH TV/R | TV/R |
| VCR | VCR | HOME SMART | Smart |
| CD | CD | C | Yellow |
| DVD | DVD | D | Blue |
| TAPE | Tape | A | Red |
| MD | MD | APP MEDIA | Media |
| TUNER/ BAND | Tuner/Band | B | Green |
| | Stop CD | | Stop |
| I<</<< CD | | << | << |
| >>/>>I CD | | >> | >> |
| | Play CD | PLAY MODE | Play |
| MENU | Menu | E-MANUAL D.MENU | D. Menu |
| DISPLAY | Display | DISPLAY INFO | Info |
| TOP MENU DISC/DECK 1/2 | Top Menu/Disc/Deck | TOP MENU MENU | Menu |
| | Up | | Up |
| | Down | | Down |

| Original | | Sustituto | |
|---|---|---|---|
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| STEREO | Stereo | SOUND DUAL | Dual |
| SURROUND | Surround | SETTINGS OPT | Options |
| SFC | SFC | AD SUBT | Subt |
| TEST | Test | RETURN BACK | Back |
| DELAY | Delay | PICTURE FORMAT | Format |
| LEVEL | Level | ECO 3D | 3D |
| + | + | + CH | Ch + |
| - | - | CH - | Ch - |
| VOL + | Vol + | + VOL | Vol + |
| VOL - | Vol - | VOL - | Vol - |
| MUTING | Muting | MUTE | Mute |
| | Power Tape | SHIFT + | Shift + Power |
| | Stop Tape | SHIFT + | Shift + Stop |
| | Play Tape | SHIFT + PLAY MODE | Shift + Play |

| Original | | Sustituto | | Original | Sustituto |
|---|---|---|---|---|---|
| I <</ << Tape | | SHIFT + << | Shift + << | | |
| >>/ >>I Tape | | SHIFT + >> | Shift + >> | | |
| Top Menu/ Disc/ Deck | | SHIFT + TOP MENU / MENU | Shift + Menu | | |
| 1 CD- Tape | | 1 | 1 | | |
| 2 CD- Tape | | 2 | 2 | | |
| 3 CD- Tape | | 3 | 3 | | |
| 4 CD- Tape | | 4 | 4 | | |
| 5 CD- Tape | | 5 | 5 | | |
| 6 CD- Tape | | 6 | 6 | | |
| 7 CD- Tape | | 7 | 7 | | |
| 8 CD- Tape | | 8 | 8 | | |
| 9 CD- Tape | | 9 | 9 | | |
| 0 CD- Tape | | 0 | 0 | | |
| >10/ - / - - CD- Tape | | -/-- GUIDE | Guide | | |
| Direct Tuning/ Disc Ente | | REPEAT TEXT | Text | | |
| | | | | | |
| | | | | | |

| Original | | Sustituto | |
|---|---|---|---|
| | Power VCR | | Power |
| DIMMER | Dimmer | FAV PRE-CH | Pre Ch |
| VCR | VCR | HOME SMART | Smart |
| TAPE | Tape | A | Red |
| TV | TV | SEARCH TV/R | TV/R |
| CD | CD | C | Yellow |
| DVD | DVD | D | Blue |
| TUNER/ BAND | Tuner/Band | B | Green |
| MD | MD | APP MEDIA | Media |
| | Stop | | Stop |
| | I<</<< | | << |
| | >>/>>I | | >> |
| | Play | PLAY MODE | Play |
| 1 | 1 VCR | 1 | 1 |
| 2 | 2 VCR | 2 | 2 |
| 3 | 3 VCR | 3 | 3 |
| 4 | 4 VCR | 4 | 4 |

| Original | | Sustituto | |
|---|---|---|---|
| 5 | 5 VCR | 5 | 5 |
| 6 | 6 VCR | 6 | 6 |
| 7 | 7 VCR | 7 | 7 |
| 8 | 8 VCR | 8 | 8 |
| 9 | 9 VCR | 9 | 9 |
| 0 | 0 VCR | 0 | 0 |
| ≥10/-/-- | >10/-/-- VCR | -/-- GUIDE | Guide |
| DIRECT TUNING DISC ENTER | Direct Tuning/Disc Ente | REPEAT TEXT | Text |
| VOL + | Vol + | + VOL | Vol + |
| VOL - | Vol - | VOL - | Vol - |
| MUTING | Muting | MUTE | Mute |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| TOP MENU DISC/DECK 1/2 | Top Menu/Disc/Deck | TOP MENU MENU | Menu |

| Original | | Sustituto | |
|---|---|---|---|
| DISPLAY | Display | DISPLAY INFO | Info |
| MENU | Menu | E-MANUAL D.MENU | D. Menu |
| STEREO | Stereo | SOUND DUAL | Dual |
| SURROUND | Surround | SETTINGS OPT | Options |
| SFC | SFC | AD SUBT | Subt |
| TEST | Test | RETURN BACK | Back |
| DELAY | Delay | PICTURE FORMAT | Format |
| LEVEL | Level | ECO 3D | 3D |
| + | + | CH + | Ch + |
| - | - | CH - | Ch - |
| Power Tuner / Band | | SHIFT + Power | Shift + Power |
| 1 Tuner / Band | | SHIFT + 1 | Shift + 1 |
| 2 Tuner / Band | | SHIFT + 2 | Shift + 2 |
| 3 Tuner / Band | | SHIFT + 3 | Shift + 3 |
| 4 Tuner / Band | | SHIFT + 4 | Shift + 4 |
| 5 Tuner / Band | | SHIFT + 5 | Shift + 5 |
| 6 Tuner / Band | | SHIFT + 6 | Shift + 6 |

| Original | | Sustituto | |
|---|---|---|---|
| 7 Tuner / Band | | SHIFT + 7 | Shift + 7 |
| 8 Tuner / Band | | SHIFT + 8 | Shift + 8 |
| 9 Tuner / Band | | SHIFT + 9 | Shift + 9 |
| 0 Tuner / Band | | SHIFT + 0 | Shift + 0 |
| >10/-/-- | | SHIFT + -/-- GUIDE | Shift + Guide |