Original		Sustituto	
POWER	Power		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TUNER/BAND	Tuner/Band	LIST SMART	Smart / List
FM MODE	FM Mode	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
≥10	>10	-/-- GUIDE EPG	Guide / EPG / -/--
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
CD	CD	SHIFT + CD-STB 3	Shift + 3
I<< CD		PRESET- I<<	I<< / Preset-

Original		Sustituto	
>>I	>>I CD	PRESET+ >>I	>>I / Preset+
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
▶	Play CD	SLOW ▶	Play / Slow
II	Pause CD	STEP-FREEZE II	Pause / Step / Freeze
■	Stop CD	HOLD ■	Stop / Hold
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
DECK1/2	Deck 1/2	HOME MENU	Menu / Home
<<	<< Deck	▼	Down
>>	>> Deck	▲	Up
REC PAUSE	Rec Pause Deck	REC MODE ●	Rec / Rec Mode
<	< Deck	◀	Left
■	Stop Deck	OK	OK
▶	> Deck	▶	Right
ON/FLAT	On Flat	TITLE SOUND	Sound / Title
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
L BA	Balance L	CH PAGE −	CH- / Page-
NCE R	Balance R	+ CH PAGE	CH+ / Page+

Original	Sustituto	Original	Sustituto
EQ Space Mode	Subtitle / EQ		
Volume-	Vol -		
Volume+	Vol +		